

Process Name/ Title:

PACKING INSTRUCTION

Document No:

Effective Date:

1

WI-QAD-QAC-311

March 20, 2025

WORK INSTRUCTION Product Code/Name:

Customer Code/ Customer:

Rev. No.:

Page No.:

Page 1 of 1

			7N0101		TR	J	Rev. No.:	1	Page No.:	Page 1 of 1	
No.	Work Procedure/ Illustration							Records/Remarks/ Quality Pointers			
								QTY/BOX	54 pcs.	9pcs. x 6 bundles	
1	Spread vinyl sheet inside the box							MATERIAL NAME	DIMENSION	QUANTITY	
			<u>La companya da managan da managa</u>					Oricon bo	x 518 x 353 x 241mm	1	
2								Vinyl shee	t 1520 x 1500mm	1	
		box		11 1				Partition board	343 x 510mm	2	
	(9pcs* 2	2 bundles)						Vinyl bag	300 x 200mm	6	
	Lay out partition		N					$\frac{1}{1}$ 2. Ensure tha	oplicable only in QC t all MR switch are inyl bag applicable	bended before	
3	boa Put the p	ard. products bundles)					The MR switch portion must be bend during inspection.				
4	boa Put the p (9pcs x 2							Bend the MR SW wire from the end of tube. Put the 1 bundle in vinyl bag together with CSW and MR switch part.			
⑤	Fold the vinyl sheet. Put NBP Identification tag at the top Then put the Warehouse Identification tag at front side of the box.		Note: If need to attach 4M tag, put it at the upper left side.								
								Prepared by	Checked by Approx	ved by Noted by	
03/20/2025	Change control number from WI-ENG-PDE-504 to WI-QAD-QAC-311 Add note & illustration for bending of MR switch wire		S. Malabuyoc		R. Pascua	n/a	Çmaroleyu (Jua M			
05/10/2022 Eff. Date	0 Rev. No.		Initial Issue Details of change	K. Doria Prepared	J. Loterte Checked	C. Villanueva Approved	A. Arañes Noted	(§). Malabuyoc Establish Date: M	TD. Dadùtta	n/a n/a	