

Process Name/ Title:
PACKING INSTRUCTION

7R0106

WORK INSTRUCTION
Product Code/Name:

Customer Code:

TRMX

Document No: WI-QAD-QAC-187

Effective Date: July 2, 2024

2

Rev. No.:

Page No.:

Page 1 of 1

No.	Work Procedure/ Illustration		1	Records/Remarks/			
140.	WORK I SOCIALIS I MASILATION			0. "	Quality Pointers 60pcs*		
1				Qty/box	240pcs.	4bdls	
	Put Vinyl Sheet (1250 x 1250) inside TRMX box.			Mat'l name	Dim.	Qty.	
				TRMX box	544*370* 228mm	1	
				Vinyl sheet	1250*1250	1	
				Partition board	343*510	1	
				Plastic Vinyl bag	420*280	4	
2	Put products (60pcs*2bdls) with opposite direction.			Note:	5 is applicable onl	y in FG	
3	Put partition board.						
4	Put products (60pcs*2bdls) on 2nd layer with opposite direction.						
5	Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at the right side of the box.						
03/03/004		The state of the s	Note : If need to attach 4M tag Put 4M tag at the left side	Preparerd	Checked /	Appyeyed	
07/02/2024 08/16/2021	2 Change viryl sheet size from 1520 x1500 to 1250 x1250 S. Malabuyoc R. Pascua O. Merin Transfer document from WH-ENG-PDE-214 to WH-QAD-QAC-187. Change dimension of the box from 610°381′178mm to 544°370′228mm and change size of partition board from 342°584 to 343°510 M.Lumbres E. Mendoza			ML/	\ kc		
12/01/2020 Eff./Rev. Date	0 Rev. No.	n and change size of partition board from 342*584 to 343*510 Initial Issue R. Pei Details of change Rev		\$. Malabuyot Est. date:	P. Pascua December 1, 2020	O.Merin	
LIIJNEV. Dale	INSV. INU.	Ret	oneuk Approve	Lat. udite.	200011DE1 1, 2020		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)
MASTER COPY