
			WORK INSTRUCTION						Effec	Effectivity Date:		May 24, 2024		
			Process Name/Title: CLAMP ASSEMBLY PROCESS							Validity Date:		n/a		
	- 1		Model code/Part number:	946B / 7N0074-7020A	Customer: TRJ	Car Model:	LE	XUS-ES	Docu	ment No.:		WI-ENG-PDE-8	348	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO		Revis	sion No.:	0	Page No.:	1 of 5	
				parts; Black tape; Green tape	ts; Black tape; Green tape					JIG:		1.Clamp assembly jig		
NO	NO.		ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POINTERS		
1	1		Table Lay-out	Assy parts Assy parts	Black tape/ Tape holder				p du	Be sure to wear prescribed personar otective equipmering operation (gloringer cots, etc.) Housekeeping Maintain and alway practice 5's. Personal things the workplace is rohibited. Keep it your locker. Alert level or any trouble, infort expending the corrective action.	Document of the property of th	1. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance 2. Refer to WI-ENG-PDE-122 for Taping assembly process 1. No missing parts/tools 2. No excess parts/tools 2. No excess parts/tools CLAMPILLUSTRATION CONNECTOR ILLUSTRATION COOD OGOD OG		
	i	Revision History						L	Prepared by	Reviewed by	Approved by	Noted by		
05/24/24	0	Initial issu	ie.			D. Castillo	C.Villanuev	A. Arañes	n/a	Jestulo D. Castillo	fort for C. Villanueva		n/a	
Eff. Date	-			Details of Change		Revised	a Reviewed	+ +	Noted 4	Est. Date:	May 24, 2024	A. A ra nes	ıva	



WORK INSTRUCTION Effectivity Date: May 24, 2024										
					Effectivity Date:	May 24, 2024 n/a				
		Process Name/Title:		P ASSEMBLY PRO	Validity Date:					
		Model code/Part number:	946B / 7N0074-7020A Customer: TRJ Car Model: LEXUS-ES				Document No.:	WI-ENG-PDE-848		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO)	Revision No.:	0	Page No.:	2 of 5
PARTS:	2. Blac		3. Green tape	JIG:	1. Clamp assembly jig					
NO.	PROCESS NAME		WORK F	TOOLS/PPE	(QUALITY POIN	TERS			
2	CLAMP	Clamp setting		82711-52 82711-52 82711-52 82711-52 82711-52 82711-52 82711-52	1		TCH ASSEMBLY TNOOT4 NBC	STANDARD TAPING FOR CLAMP One wind for under tape Important reminders/Note/s: 1. Please check the Clamp first before start of assembly to avoid wrong use of clamp.		
			1. Get 1pc. of clamp	82711-52090 (W) then set	to clamp location	1 using both hands.		2. No wron	aged clamp ng use of clamp ng use of tape sing clamp	
			2. Initially attach Blac	ck tape on clamp location of	l using both hand	ls.		600D	CLAMP ILLUSTRATION NG NG	


			WC	Effectivity Date:	May 24, 2024				
		Process Name/Title:		CLAMP ASSEMBLY PRO	CESS	Validity Date:	n/a		
		Model code/Part number:	946B / 7N0074-70	Car Model: LEXUS-ES	Document No.:	WI-ENG-PDE-848			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 5
PARTS:	Assy parts Green tape					JIG:	1. Clamp a	ssemby jjig	
NO.	PROCESS NAME		ı	TOOLS/PPE	QUALITY POINTERS				
3	CLAMP	Clamp assembly	above picture for correct se 6098-3810 (W) to Receiver set the harness in jig. Last, the stopper then press by T sequence light of location (3. Get the GREEN tape anwinds) on location 1 using	d conduct spot taping (2~3 both hands. Go sound will be cts Green tape. Press the SW ue to clamp location 2 if	71	ormality, STOP and e leader. WAIT for rocess.	1. Make terminal 2. Make taping. 1. No dama 2. No wron 3. No wron 4. No miss	CONNECTOR ILLUST	Note/s: ween the clamp



			Effectivity Date:	May 24, 2024							
		Process Name/Title: CLAMP ASSEMBLY PROCESS						Validity Date:	ity Date: n/a		
		Model code/Part number:	946B / 7N0074-7020A	Customer:	TRJ	Car Model:	LEXUS-ES	Document No.:		WI-ENG-PDE-8	348
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	ı	Revision No.:	0	Page No.:	5 of 5
PARTS:	TS: 1. Assy parts							JIG:	n/a		
VISUAL INSPECTION											

CLAMP ASSY

7N0074-7020A



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.