Process Name/ Title: Document No: WI-QAD-QAC-079 PACKING INSTRUCTION WORK INSTRUCTION Effective Date: July 10, 2021 Product Code/Name: Customer Code: Rev. No.: 2 Page No.: Page 1 of 1 7M0365 TRJ Records/Remarks/ Work Procedure/ Illustration **Quality Pointers** 18pcs* **72** Qty/box 4bdls Mat'l Dim. Qty. name Oricon 386*557 1 box (1) Spread Vinyl sheet inside Vinyl 1520* Oricon box. 1 sheet 1500 **Partition** 343*510 1 board **Plastic** 420*280 4 vinyl bag Plastic vinyl bag of (2) Note: Put products MR SW assy (18pcs*2bdls) 1. Step number 5 is applicable only in QC FG Inspection. void peel off tape STRAIGHT Condition: Connector with 4 wires are placed on the side of the box Connector with 4 wires are placed on the corner of the box (3) Lay out partition board. 4 Put products (18pcs*2bdls) on 2nd layer Fold the vinyl sheet. (5) Put NBP Identification tag at the top.Then warehouse Identification D 2 300 tag at lower right side of the box. If need to attach 4M tag Put 4M tag at the upper left side of the box Prepared Approved 07/10/2021 Additional note and update location of tags in step number 5 C.Dimailig M.Lumbres E.Mendoza 10/10/2019 Change packing position (Connector with 4 wire insertion should not be bend to avoid PEEL OFF TAPE) M.Lumbres E.Mendoza 11/21/2018 Initial issue : Separate from Packing instruction WI-QAD-QAC-007 C.Dimailig M.Lumbres E.Mendoza C. Dimallig Details of change Approved Effectivity date: November 21, 2018 Eff. Date Prepared Checked ONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY