		1	WORK IN	Effectivity Date:	August 12, 2021						
		Process Name/Title:	TAPIN	IG ASSEMBLY PRO	Validity Date:	n/a					
		Product Name/Code:	970A / 17J711-7051	Customer:	NBC	Document No.:	WI-ENG-PDE-299B				
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0 Page No.: 1 of 4				
PARTS:	1. As:	sy parts				JIG:	1. Insertion jig				
NO.	-	PROCESS NAME	WORK	PROCEDURE/ ILLUST	TOOLS/PPE	QUALITY POINTERS					
1	P2	Connector setting to insertion jig (Assy parts) 1827842-1 (W)	Guide Lock Guide Lock Before Pressing	1. Get the connector 182784: set to insertion jig. Note: Follow the connector of the permission must be permission. AFTER PRESSING	Note: Check the connector before insertion. R ORIENTATION 2-1 (W) (Assy parts) using right hand then	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action. Finger COTS	1. Use the provided jig per model 2. No wrong usage of parts 3. No wrong orientation of connector 4. No damaged connector 5. No half-locked connector Note: Automatically dispose and replace the unit if once encountered Bend terminal, Difficulty of insertion, Half-locked connector. Note: If encountered abnormality, STOP and immediately CALL the attention of the leader. WAIT for further instruction and continue the process. Do not attempt to repair.				
Revision History Prepared by Reviewed by Approved by Noted by											
						Atmentage	till (li-2 Com				
Eff. Date Rev.	No		Details of Change		Prepared Checked Approved N	Noted Est. Date: Augus	st 12, 2021				
ONE DENTAL Any minute or mineropresisting including											

				Effectivity Date:	August 12, 2021								
		Process Name/Title:			TAPING ASS	Validity Date:		n/a					
		Product Name/Code:	970A	1	17J711-7051P	Customer:	NBC	Document No.:			WI-ENG-P	DE-299B	
	Purpose:		PROTOTYPE			PRE-LAUNCH	PRE-LAUNCH MASSPRO		Revision No.:		Page No.:	2 of 4	
								•	T	1	•		
	2. CIVUS	. Assy parts . CIVUS 0.13 W L=183±2mm; Y L=178±2mm; G L=181±2mm; R L=178±2mm; BR L=176±2mm; L L=175±2mm; LG L=176±2mm; P L=175: L=185±2mm; B L=179±2mm; GR L=180±2mm [GROUP 2 wires]							±2mm; JIG		1. Insertion jig		
NO.	PF	ROCESS NAME			WORK PROCE	OURE/ ILLU	ISTRATION	TOOLS	QUALITY POINTERS				
2	P2				NG Long terminal	1. Get the wire and hold it 5mm away from terminal. 2. Half insert the wire. 3. Release gain 5mm away from terminal 5. Fully inserted wires (avoid bending during insertion) Note: Follow the insertion sequence based on the visual reference	Finger C		2. No te 3. No de 4. Make inserted 5. Must insertior 6. No be Note: 028 j Note: 1 replace Bend te Half-lo Note: STOP attent furthe proces	have slight Manager in the control of the lear instruction at a sign of th	dispose and ce encountered ulty of insertion, or. d abnormality, tely CALL the der. WAIT for and continue the		

					WORK INSTRUC	Effectivity Date:		August 12, 2021					
		Process Name/Title:			TAPING ASS	SEMBLY PI	ROCESS	Validity Date:			n/s		
	5	Product Name/Code:	970A	1	17J711-7051P	Customer:	NBC	Document No.:			WI-ENG-P	DE-299B	
	4	Purpose:		PROTOTY	YPE	PRE-LAUNCH	☐ MASSPRO	Revision No.:		0	Page No.:	3 of 4	
								<u> </u>	1	1			
PARTS:	1. Assy լ 2. Black	parts sunprene tube \$7 L=55±5			JIG		tor jig						
NO.	PF	ROCESS NAME			WORK PROCE	DURE/ ILLU	STRATION	TOOLS/	PPE	QI	JALITY P	POINTERS	
3	P2	Wire insertion to Black Sunprene tube \$7 L=55±5mm	tube Ø7 L hand ther jig using ri 3. Inser	n insert the right hand. Use the adeasily inserved the wireserved one pressure of the pressur	daptor jig to ert wires. Button L R	ng right hand.	2. Hold the Group 2 wires (11pcs) using right hand. S. Hold the wires using right hand then gently pull the connector from jig. Check the insertion condition.	Adapto Finger Co		1. No wrong use of parts. 2. No remaining wires outside Black sunprene tube 3. No cut tube STANDARD TUBE APPEARANCE GOOD NG NG			

					Effectivity Date:	Effectivity Date:			August 12, 2021				
		Process Name/Title:			TAPING ASS	Validity Date:	Validity Date:			n/a			
		Product Name/Code:	970A	1	17J711-7051P	Custo	omer: NBC	Document No.:			WI-ENG-P	DE-299B	
		Purpose:	PROTOTYPE			PRE-LAUNCH MASSPRO		Revision No.:		0	Page No.:	4 of 4	
								•	•				
PARTS:	1. Assy _l	sy parts							JIG		1. WIP Holder		
NO.	PF	ROCESS NAME		WORK PROCEDURE/ ILLUSTRATION						Ql	JALITY F	POINTERS	
4		Connector lock	Push strongly Push point R 1. Push the double lock using left & right thumb. (Same timing) 2. Check the connector lock after locking Note: Please refer to GL-PRO-ASY-017 for the verification of connector lock.					n/a		No damaged double lock. No half lock connector			
5	P2	Pass WIP to P3					1. Pass WIP to WIP Holder. Note: One piece flow.	WIP HO	LDER		1. No WIF	overflow	