WORK INSTRUCTION		STRUCTION				Effec	ctivity Date:		August 08, 2024				
			Process Name/Title:	TAPIN	IG ASSEMBLY PROC	ESS			Valid	lity Date:		n/a	
			Model code/Part number:	310B / 7M0522-7021	Customer: TRJ	Car Model:	TOYO	TA-RAV	Docu	ument No.:		WI-ENG-PDE-4	03B
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO		Revi	sion No.:	2	Page No.:	1 of 6
PARTS: 1.Assy part; Black VM tube (Sunprene) Ø9 L=120±3mm; Black Tape									JIG:	n/a			
N	0.	F	ROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION				TOOLS/PPE		QUALITY POIN	ITERS
					Table Lay-out Black VM tube (Sunpren Ø9 L=120±3mm	e)			b t	afety Instructi Be sure to wear prescribed persor rotective equipm during operation (gloves, finger core etc.)	al ent		
1		P2	Table lay-out	Ass	ck Tape/				Housekeepin Maintain and alw practice 5's. Personal things the workplace is prohibited. Keep it your locker.	ays 1. No mi on 2. No ex	No missing parts/tools No excess parts/tools		
				10 (m) 10	(a Alone (approximate of the Alone (approximate of the Alone (approximate of the Alone of the Al	e Holder			_ A	Alert level or any trouble, inf the Assembly Assistant Supervis or Line Leader fo mmediate correct action.	sor or		
		I		Revision History					1	Prepared by	Reviewed by	Approved by	Noted by
08/08/24	2	Transfer Improved	Taping 2 process from P1 due to	o process improvement. Inclusion of car model "T	OYOTA-RAV 4" and Measurement.	D.Castillo	C.Villanuev a	A. Arañes	N/A	_			
05/12/23	1	Inclusion (sunpren		the Important remnders/note/s and document ref	erences; standardize VM gtube	J.loterte	C.Villanuev a	A. Arañes	N/A	Latus	South Tiffor	ALCO ALCO ALCO ALCO ALCO ALCO ALCO ALCO	
02/19/22		Initial iss	ue.			K.Doria	J.Loterte	C.Villanuev a	. Arañes	D. Castillo	C. Villanueva	A. Araños	N/A
Eff. Date	Rev. No	. No Details of Change					Reviewed	Approved	Noted .	Est. Date:	February 19, 202	2	



			WORK IN	Effectivity Date:	August 08, 2024						
		Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:	n/a			
		Model code/Part number:	310B / 7M0522-7021	Customer:	TRJ Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-40)3B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO	Revision No.:	2	Page No.:	2 of 6	
		parts tape					JIG:	n/a			
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS			
2	P2	Y-taping	Note: Do not exert excessive force during pulling & winding of tape. 2. Hold two vinyl tube using left hand at Make 1 winding pre-tape before shifting the tape down to vinyl tube until tape w taping direction 2. Hold two vinyl tube using left hand at Make 1 winding pre-tape before shifting the tape down to vinyl tube until tape w 4. From COT, winding the tape down to vinyl tube (1/2 shifting) until tape width	tape shifting 5. From to side of	tape shifting 1/3 below taping direction 1/2 below 20±3mm n vinyl tube, winding the of corrugated tube then gs. After taping, check the	cut the tape after 2	Measuring tape 6789 1234 5678 9	1. Vsed of tape s BLAC 2. Pleas measuris measure 1. No loose 2. No peel- 3. No flip-o 4. No wron.	e use calibrated/veng tape when gettiement. tape off tape out tape g dimension g use of tape	sy visualization should be erified	




	WORK INSTRUCTION Effectivity Date: August 08, 2024										
		Process Name/Title:	Validity Date:	n/a							
		Model code/Part number:	310B / 7M0522-702	APING ASSEMBLY PRO Customer: TRJ	Car Model:	TOYOTA-RAV 4	Document No.:	WI-ENG-PDE-403B			
		Purpose:	□ PROTOTYPE	PRE-LAUNCH	MASSP		Revision No.:	2	Page No.:	3 of 6	
							1				
PARTS:	1. Assy 2. Black						JIG:	n/a			
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(QUALITY POIN	TERS		
3	P2	Taping 2 COT to wire near terminal	1. Get Black tape, hold corrugated tube using left hand then start pre-taping. 20±3mm	L	gated tube up to gusing right hai	nd.	Measuring tape	5. No wrong 6. No missi Import 1. Plea measu measu Docum 1. Refe	e tape off tape ut tape g dimension g use of tape	nd Note/s: d/verified letting the	



			WORK INS	Effectivity Date:	August 08, 2024						
		Process Name/Title:	TAPIN	Validity Date:	n/a						
		Model code/Part number:	310B / 7M0522-7021	Customer: TRJ	Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-40)3B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO	Revision No.:	2	Page No.:	4 of 6	
PARTS:	1. Assy 2. Black	parts VM tube (Sunprene) Ø9 L=1:	20±3mm	3. Black Tape			JIG:	n/a			
NO.	P	ROCESS NAME	WORK F	WORK PROCEDURE/ ILLUSTRATION					QUALITY POINTERS		
4		Wire insertion to Black VM tube (Sunprene) Ø9 L=120±3mm	L 20mm R 2. Insert the Sunprene tube to COT 20 width).	VM tube (Sunprene	rires using left han	d and insert the Black h using right hand.	n/a	1. No wrong	use of parts		
5	P2	Taping 3 Corrugated tube to VM tube (Sunprene)	1. Hold the COT using left hand and the end of Sunprene tube up to the to 39±3mm. 20±3mm 20±3mm	1m3 4 Imeasure	3. Afte	e tube using left ng using right hand. If taping, check the trement and taping on.	The same and the s	1. Please tape when	tape off tape it tape g dimension g use of tape	ement.	







-		WORKING	TRUCTION		Iru on Di			
	Process Name/Title:	WORK INS	Effectivity Date: Validity Date:		August 08, 20 n/a	24		
	Model code/Part number:	310B / 7M0522-7021	Car Model: TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-4	03B	
	Purpose:	PROTOTYPE	Customer: TRJ	MASSPRO	Revision No.:	2	Page No.:	6 of 6
PARTS: 1. A	ssy parts	٨			JIG:	n/a		
		Z VIS	SUAL INSPECTION/ QU	JALITY CHECKPOINTS	•			
P2			7M05	22-7021				
				William Control of the Control of th				Y-1
				an a				
	1							
					2			
						(3)		-
1			"大学 "	9 (0 1 2"3	4 5 6 7 8 9 20 1 2 3 4			
						18		
		(1)(2)(3) I	No Missing Ta	ape(Black Tape)				

NBC (Philippines)
MASTER COPY