

NO. PROCESS NAME  WORK PROCEDURE/ ILLUSTRATION  Table Lay-out  Black Corrupated Lube (No. Still)  AVSSI 0.3 White Les 903.3mm  AVSSI 0.3 White Les 903.3mm  AVSSI 0.3 White Les 903.3mm  Revision History  Revision History  Propare by Revised by				WORK INS	STRUCTION		July 15, 2024				
PARTS: 1. Connector: 7283-5526-70 (Y) 3. AVSS10.3 Black/White L= 600x3/mm VO. PROCESS NAME  WORK PROCEDURE/ ILLUSTRATION  Table Lay-out  Table Lay-out  Black Compared to the (No Sig) of 5 L=593-5mm  Table Lay-out  Ta			Process Name/Title:	Validity Date:		n/a					
PARTS:  1. Connector 7C83-5524-70 (Y) 2. AVSSI 0.3 Bitack/White Ls 600u3:mm 4. Black Corrugated tube (No Sith) 65 L-503u5mm 7. Sold Process NAME  WORK PROCEDURE/ ILLUSTRATION  Table Lay-out  Table Lay-out  Safety Instruction prescribed personal tube (No Sith) gost Lossaus for sold personal tube (N			Model code/Part number:	NB8 / 7N0208-7020a	Customer: TRJ	RU-LEGACY	Document No.:		WI-ENG-PDE-972		
NO. PROCESS NAME  WORK PROCEDURE/ ILLUSTRATION  Tools/PPE  QUALITY POINTERS  Table Lay-out  Black Cornigated tube (No Siti) g85 L=593.45mm  Table Lay-out  Safety Instruction Be sure to wear protective expinent during operation (gloves, finger ods, etc.)  (gloves, finger ods, etc.)  1. Molifolia and always protective expinent signer ods, etc.)  Protective expinent signer ods, etc.)  1. Molifolia and always protective expinent signer ods, etc.)  Protective expinent signer ods, etc.)  1. No wrong use of parts protective expinent signer ods, etc.)  No excess/lacking of parts  No excess/lacking of parts  No excess/lacking of parts  No excess/lacking of parts  Programed by Reversed by Reversed by Aparend by Apar			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	1 of 5
Table Lay-out    Safety Instruction   Be sure to wear prescribed personal protective equipment during operation (gives, finger cots, etc.)	PARTS:	2. AVS	Sf 0.3 White L= 690±3mm	4							
Black Corrugated ube (No. Sit) grotective equipment (gloves, finger cots, etc.)  Connector 7C83- 5524-70 (Y)  Black Corrugated ube (No. Sit) grotective (see an experiment of the workplace is prohibited. Keep it in your locker.  Insertion jig  AVSST 0.3 Black/White Le 690±3mm  Revision History  Revision History  Prepared by Reviewed by Approved by Noted by  Prepared by Reviewed by Approved by Noted by  Alternance: C. Villeages A. Alternance C. Villeages A. Alternance C. Villeages (a) Alternance C. Vill	NO.	P	ROCESS NAME	WORK I	TOOLS/PPE	(	QUALITY POIN	TERS			
07/15/24 0 Initial issue.  A.Hernandez C. Villanueva A. Arañes n/a	1	Table Lay-out  Safety Instruction Be sure to wear prescribed personal protective equipment (glowes, finger cots, etc.)  Housekeeping 1. No wrong u practice 5's 2. Personal things on the workplace is prohibited. Keep it in your locker.  AVSSI 0.3 Black/White L= 690±3mm  AVSSI 0.3 White L= 690±3mm  Leader for immediate corrective action.									
07/15/24 0 Initial issue.  A. Hernandez C. Villanueva A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a Details of Change  Revised Reviewed Approved Noted Est. Date: July 15, 2024				Revision History				Prepared by	Reviewed by	Approved by	Noted by
Details of Change   Revised   Reviewed   Approved   Noted   Est. Date:   July 15, 2024			ue.	Dubits of Observe			1	_		A. Arades	n/a
	Lii. Date Rev. No	)		Details of Change		Kevised   Keviewed	Approved No	oted  Est. Date:	July 15, 2024		




			WORK INSTRUCT	Effectivity Date:					
		Process Name/Title: OFFLINE ASSEMBLY PROCESS				Validity Date:	ate: n/a		
		Model code/Part number:	NB8 / 7N0208-7020a Cust	omer: TRJ	Car Model: SUBARU-LEGACY	Document No.:		WI-ENG-PDE-97	72
		Purpose:	□PROTOTYPE □ PRE-	LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 5
PARTS:		nector 7C83-5524-70 (Y) Sf 0.3 White L= 690±3mm	3. <i>I</i>	JIG:	1. Insertion jig				
NO.	F	PROCESS NAME	WORK PROCEI	OURE/ ILLUSTR	ATION	TOOLS/PPE	C	UALITY POINT	TERS
4	offline	Wire Insertion to connector 7C83-5524-70 (Y)	White  1. Get the White wire and insert to terminal slot 1 using right hand.  Black/White  2  3. Get the Black/White wire and insert to terminal slot 2 using right hand.	2. After insertion right thumb. Slot  4. After insertion, hand and then he	of White wire, press the button using for Black/White wire will be open.  Press the insertion jig lock using left old the wire and gently pull out the g using right hand.		Connect No Docume	nt references:	GOOD 




NB	C	WORK INSTRUCTION						Effectivity Date:		July 15, 2024		
		Process Name/Title: OFFLINE ASSEMBLY PROCESS						Validity Date:	n/a			
		Model code/Part number:	NB8 /	7N0208-7020a	Customer:	TRJ	Car Model:	SUBARU-LEGACY	Document No.:		WI-ENG-PDE-	972
		Purpose:	PROTOT	YPE	PRE-LAUNCH	1	MASSF	PRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	n/a								JIG:	n/a		
VISUAL INSPECTION/QUALITY CHECKPOINTS												

## **OFFLINE INSERTION**

## 7N0208-7020a







(1) No Wrong Insertion

2 No Terminal Backing Out

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.