

Process Name/ Title: Document No: WI-QAD-QAC-061 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: July 5, 2024

		7	Product Code/Name:	Custome	er Code:	Lilective			July 5, 20.		
			7L0053		Rev. No.: 3		3	Page No.: Page 1 of 1			
No.	Work Procedure/ Illustration								Records/Remarks/ Quality Pointers		
<u>(1)</u>	23 Put Vinyl							Qty/box	80	40pcs *2bdls	
1		1250 x 1250) carton box.	A NAVERAGE	Contract of the				Mat'l name	Dim.	Qty.	
	IIISIGE	carton box.		多公局			^	DC carton	1131*781	1	
			3				<u>/</u> 3	Vinyl sheet	1250*1250	1	
								Vinyl bag	420*280	2	
2	Put first bdl of products. (40pcs.)							Note: 3 Step number 5 is applicable only in <b>QC FG Inspection.</b>			
3	Put second bdl with opposite direction. (40pcs.)										
<u>3</u> 4	Fold the vinyl sheet										
(5)	Close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box) .		Note: If need to attach 4M tag Put 4M tag at the left side								
							Prepare	Che	eck	Approve	
07/05/2024	3	Change Vinyl Sheet Size	from 1520x1500 to 1250x1250; Change picture of no. Addition of no. 5; Modify note.	1; Modify no. 4 and J. De	e La Cruz D.Dadulla	R.Pascua					
12/20/2021			per bundle from 28 to 40 pcs. and from 56 to 80 pcs. per box		M. Garcia R.Alcantara A. Arañes		8/			1./	
10/22/2020			y per bundle from 25 to 28 pcs. and from 50 to 56 pcs tial Issue: Removal of Silica gel and Bubble sheet		Dimailig M.Lumbres  Dimailig M.Lumbres	E Mendoza  E Mendoza	J. De Ocr	uz D.Da	dulla	R Badua	
Eff./Rev. Date	Time look internet a circular and part and passed check						stablished.		10/15/201	8	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

**NBC (Philippines) MASTER COPY**