

PACKING INSTRUCTION

WI-QAD-QAC-169

Document No:

		WORK INSTRUCTION			00	October 11, 2024		
		Product Code/Name: 7L0098	Customer Code: TRQSS	Rev. No.: 3	Page No.	.: Page	e 1 of 1	
No.		Records/Remarks/ Quality Pointers						
		Qty/box	40pcs x 2bdls					
1	Put Vinyl Sheet (1250 x 1250)				Mat'l name	80 <u>3</u> Dim.	Qty.	
	inside carton box.			DC carton	1131*781	1		
			The state of the s		Vinyl sheet	1250*1250	1	
					Vinyl bag	420*280	2	
2	Put first bdl of products. (40pcs/bdl)				Note : Step nur in QC FG I	mber 5 is app nspection.	licable only	
3	Put second bdl on the other side with opposite direction (40pcs/bdl)							
4	Fold the vinyl sheet							
	Close the flaps and put	Value						

ID tag (Inner tag at the top of the plastic and Outer tag at the right (5) side of the front of the box).





Note: If need to attach 4M tag Put 4M tag at the left side

						Prepare	Check	Approve
10/11/2024	3	Change quantity per bundle from 30 pcs to 40 pcs Change total packing quantity from 60pcs to 80pcs	A. De Chavez	D.Dadulla	R.Pascua			1
6/4/2024	2	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua	11-		11.
8/24/2022	1	Update step no. 4 regarding 4M, inner tag & outer tag location	M. Garcia	R. Alcantara	A.Arañes	Alex	Muse	MH.
05/18/2020	0	Initial Issue	C.Dimailig	M.Lumbres	E Mendoza	A. De Chavez	D.Dadulla	R.Pascua
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date:		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) MASTER COPY