
				WORK INST	Effectivity Date:		June 18, 2024					
			Process Name/Title:	CLAMF	P ASSEMBLY PROC	CESS			Validity Date:		n/a	
	-11		Model code/Part number:	900B.910B / 7N0104-7020A	Customer: TRJ	Car Model:	LEXUS	S-NX/RX	Document No.:		WI-ENG-PDE-8	309
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO		Revision No.:	0	Page No.:	1 of 6
PARTS:							JIG:		1. Assembly jig			
NC	).	Р	ROCESS NAME	WORK P	ROCEDURE/ ILLUSTR		TOOLS/PP	E	QUALITY POINTERS			
1		CLAMP	Table lay-out	Clamp tray/ Clamp 82711-52090 (W)  Assy parts  Sky blue tape/  Black t	TABLE LAY-OU  Master Sample  ape/e	Clamp t			Safety Instruct Be sure to wea prescribed persor protective equipr during operation (g finger cots, etc.)  Housekeepin 1. Maintain and al practice 5's. 2. Personal things of workplace is prohill Keep it in your loc.  Alert level For any trouble, in the Assembly Assi: Supervisor or Line L for immediate corruaction.	E Ways In the little of the li	ing parts in assy parss tape/tape holder go position of tape ho	f-809A-C for ss
				Revision History								
				Revision Filstory					Prepared by	Reviewed by	Approved by	Noted by
										1/		
06/18/24	0 lr	nitial issu	e.			D.Castillo C	C.Villanueva A	A. Arañes r	n/a D. Castillo	C. Villanueva	A Aranes	n/a
Eff. Date				Details of Change		Revised	Reviewed	Approved No	oted Est. Date:	June 18, 2024	/ t. / <del>182</del> 2/103	11/4
										•	•	



			WORK INSTRUCTION	Effectivity Date:	June 18, 2024				
		Process Name/Title:	CLAMP ASSEMBL	Y PROCESS		Validity Date:		n/a	
		Model code/Part number:	900B.910B / 7N0104-7020A Customer:	TRJ Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-8	09
		Purpose:	PROTOTYPE PRE-LAUNCH	MASSPRO	)	Revision No.:	0	Page No.:	2 of 6
PARTS: 1.Clamp 82711-52090(W) [3pcs] 3. Black tape [3pcs.] 4. Sky Blue tape JIG: 1.Clamp assembly jig									
NO.	F	ROCESS NAME	WORK PROCEDURE/	ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS		
2	CLAMP	Clamp setting		4. Initially attach sky bla 3 using both hands.  5. Initially attach black to 2 and 4 using both hands.	ape to location 1,	n/a	Importa  1. Check of assen clamp.  6000  82711-  1. No wron 2. No wron 3. No dam.	one wind for under on the reminders/Note the Clamp first benthly to avoid wron CLAMP ILLUSTRATION	tape  e/s:

				INSTRUCTION			Effectivity Date:	June 18, 2024			
		Process Name/Title:		AMP ASSEMBLY PRO	CESS		Validity Date:		n/a		
		Model code/Part number:	900B.910B / 7N0104-70	020A Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-8	09	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	0	Page No.:	3 of 6	
PARTS:	PARTS: 1. Assy parts JIG:										
NO.	F	ROCESS NAME	WO	RK PROCEDURE/ ILLUSTI	RATION		TOOLS/PPE	(	QUALITY POIN	ΓERS	
3	CLAMP	Clamp Assembly	3. Hold the tape on clamp locat taping. Continue the process if s  4. Hold the tape on clamp locat	Y-taping Orientation (See above picture for cocond, set the Y-taping into Y-taping the harness in jig. Last, set the wer On, Clamp On, Wire1 & Win of the leader. WAIT for further into 1. Make 3 windings of tape	goon  orrect setting oring guide. Third instruction then then cut the tap 12 was ON.	encountered abnormality continue the process. Cl	connector 6189-0407 -3810 (W) to Receiver her within the stopper  7, STOP and heck if the sequence ss the SW button after	1. Make s jig and P  1. No dama 2. No wrong 3. No missi 4. No missi 6000	ged clamp g usage of parts ng clamp ng tape  CLAMP ILLUSTRATION  NG	een stopper	

				NSTRUCTION			Effectivity Date:		June 18, 2024	
		Process Name/Title:	CLA	Validity Date:	n/a	n/a				
		Model code/Part number:	900B.910B / 7N0104-7020	0A Customer: TRJ	Car Model: LEXUS	-NX/RX	Document No.:		WI-ENG-PDE-80	9
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	4 of 6
PARTS:	1. Assy 2. Black	parts. tape [3pcs]	3. Sky Blue tape				JIG:	1.Clamp As	sembly jig	
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
3	CLAMP	Clamp Assembly (Continuation)	Stopper  Color Sensor (Sky Blue tape on clam jig will beep/buzz if color sensor olight in clamp location 4 was ON  6. Hold the tape on clamp locatic after taping. GO sound will be heat  7. After taping, CONDUCT POIN removing the harness from jig.	Y-tapi Orienta  np location 3. Make 3 winding detects Sky blue tape. Press l.  on 4. Make 3 windings of tagard.	Receiver base 2  Ings of tape then cut the tape is the SW button after taping	Conne orienta  e using both h  Continue the oth hands. Present in the other in the	ands. Clamp assembly e process if sequence ess the SW button irst, remove the er base 2. Then,	1. Make s jig and P	ged clamp g usage of parts ng clamp ng tape  CLAMP ILLUSTRATION  NG	



			Wan	/ INICTRICATION			Effectivity Date:			
	WORK INSTRUCTION Process Name/Title: CLAMP ASSEMBLY PROCESS								June 18, 2024 n/a	
	_	lodel code/Part number:	900B.910B / 7N0104-7		Car Model:	LEXUS-NX/RX	Validity Date:  Document No.:	n/a WI-ENG-PDE-809		
		urpose:	□ PROTOTYPE	PRE-LAUNCH	MASSPI		Revision No.:	0	Page No.:	6 of 6
		·								
PARTS:	1. Assy pa	arts					JIG:	n/a		
				VISUAL INSPECTION/ Q	UALITY CHE	CKPOINTS				
				7.	040	7000				
CL	<u> AIVII</u>	P ASSY			10104	1-7020 <i>P</i>	<b>\</b>			
Sant			2							
1			2	-		(3)				
										1000
				(6) (4)						N. B.
						and the	No.			
		1								No.
										2.19
		1		5						7.63
									1	
										979
					1					6 14
9 1/1	The same					5 a 2 a a 111 1 2	3 4 5 6 7 8 9 10 1	2 3 4 5	6 7 8 9 [] 1 2	3 4
4. 4	7 1 1 11	112345678	9 KIT 1 2 3 4 5 0 7 8 1	1010 1 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	W. C. S. S. S.				1 1 1 1 1 1 1	
1 (1)	2	No Missi	ng Clamp (4)	No Missing Clam	<b>1p</b> (5)	No Missing	Tape $(6)$ N	lo Missi	ing Tape	
		(W)	\ - /	(GR)			•	Sky Blu		
		( v v )		(UN)		(Black)	(:	oky biu	<b>E</b> J	