

area"

Prepare empty Oricon box

in the "after inspection

No.

(1)

	Process Name/ Title:		WI-ENG-PDE-852		
7	PACKING INSTRUCTION	Document No:			
П	WORK INSTRUCTION	Effective Date:	February 20, 2024		

Product Code/Name:

Customer Code/ Customer:

75V098

TRJ

Rev. No.:

Page No.:

0

Page 1 of 1

Work Procedure/ Illustration

Quality Pointers 100pcs* Qty/box 400 4 bdls Mat'l Dim. Qty. name Oricon 386*55* 1 box 243 **Partition** 343* 1 board 510 Vinyl 545* 4 450 bag

Records/Remarks/

Get the vinyl (plastic) bag then put the 100pcs harness. Insert products in same direction. Put the ID tag inside then fold the plastic bag.



Put products in vertical position and partition board vertically between the products. (100pcs*4 bundles with ID tag inside)



White connectors must be on top position.

Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box.





Note : If need to attach 4M tag
Put 4M tag at the left side of the box

							Prepared by	Reviewed by	Approved by	Noted by
							210	2/ 0		
							Estoriar	Nonth Tifform	HOO	
02/20/24	0	Initial Issue	C.Hernandez	C. Villanueva	A. Arañes	n/a	C.Hernandez	C. Villanueva	A. Grandos	n/a
Eff. Date	Rev. No.	Details of change	Prepared by	Reviewed by	Approved by	Noted by:	Establish Date:	February 21, 2024		