

DACKING	INICTOIL	CTION

PACKING INSTRUCTION

Document No:

WI-QAD-QAC-200

WORK INSTRUCTION Product Code/Name:

Customer Code:

Effective Date:

2

January 9, 2023

75N860

TRJ

Rev. No.:

Page No.: Page 1 of 1

No.			Records/Remarks/ Quality Pointers		
1)				400	100pcs*4bdls
	Spread Vinyl sheet inside folding box.		Mat'l name	Dim.	Qty.
			Vinyl sheet	1520*1500	1
			Partition Board	343*510	1
		and the state of t	Vinyl bag	545*450	4
2	Get the vinyl (plastic) bag then put the 100 pcs harness and place the ID tag inside then fold the plastic bag.	The state of the s			

position and partition board vertically & alternately with the products. (3) (100pcs* 4 Bundles with I.D tag inside)

Put products on vertical



White connectors must be on top position.

Put NBP Identification tag at the top then

warehouse identification

Fold the vinyl sheet.

tag at front side of the box

(4)



* If need to attach 4M tag. Put 4M tag at the upper left side of the box.

							Prepared	Checked
C	1/09/2023	2	Change document control number from WI-ENG-PDE-226 to WI-QAD-QAC-200	M. Garcia	R. Alcantara	A. Arañes		
0	1/29/2021	1	Add partition board to avoid movement of parts during shipment	R. Peñaloza	A. Shimamura	A. Arañes	mm e'i	Marie C.
C	1/27/2021	0	Initial Issuance	R. Peñaloza	A. Shimamura	A. Arañes	M. M. Sulv M. Gardia	Alcantara
E	Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Established Da	ate: 01/27/202

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) MASTER COPY Approved