

		> Change quantity from 600 to 1,200pcs, change quantity of vinyl sheet from 1 to 2pcs and vinyl bag from 6 to 12pcs				Prepared	Checked	Approved	Ī
11/05/2020	3	Change from taping of plastic bag to folding for every 100pcs.     Add partition board	R. Peñaloza	A. Shimamura	A. Arañes			5	
8/24/20	2	Change vinyl bag size from 275*405 to 280*420 Change sequence of process 1 to 3	R. Peñaloza	A. Shimamura	A. Arañes	alusar	( P D	(1)	
7/24/20	1	Change Part number from Z01-81090-G740A to Z01-81090-R740A	R. Peñaloza	A. Shimamura	A. Arañes	1 2 8	Sum		
07/20/20	0	Initial issue	R. Peñaloza	A. Shimamura	A. Arañes	R. Peñaloza	A. Shimamura		
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Established Date: July 16, 2020			



No.

## Process Name/ Title:

PACKING INSTRUCTION

Document No:

Effective Date:

WI-ENG-PDE-149

November 5, 2020

**Quality Pointers** 

WORK INSTRUCTION
Product Code/Name: Cust

Customer Code/ Customer:

Rev. No.:

Page No.:


Page 2 of 2

Z02-81090-R030B

030B/NBC Hayashi


Records/Remarks/

3





Bundle the 25 pcs
harness using 1pc. black
vinyl tie



(8) Get vinyl (plastic) bag then put 4 bundles inside. Note: Directions should be alternate for each bundle. Put the ID tag inside then fold the plastic bag.



Arrange the packed harness in box as shown in the illustration. (100pcs\*2plastics with I.D tag inside ) on both side.

1st layer: 2 plastics
2nd layer: 2 plastics
3rd layer: 2 plastics

Total of 6 plastics



(10)

<u> 3</u>

Fold the vinyl sheet.

Put NBP Identification tag at the top then warehouse Identification tag at front side of the box.





Note: If need to attach 4M tag
Put 4M tag at the right side