
			WORK INSTRUCTION								ectivity Date: June 6, 2024			
			Process Name/Title: OFFLINE ASSEMBLY PROCESS							Validity Date:		n/a		
			Model code/Part number:	400B / 7M0596-7020B Customer: TRJ Car Model: TOYOTA-VITZ					TA-VITZ	Document No.:		WI-ENG-PDE-124		
			Purpose:	PROTO	DTYPE	PRE-LAUNCH	MASSP	RO		Revision No.:	4	Page No.:	1 of 6	
PARTS: 1		1. Assy	Assy parts (IRRAX A Rope-Lay 0.3 wires B L=177); Connector 6098-3803 (B)							JIG:		1. Insertion jig 2. Locking jig		
N	0.	Р	ROCESS NAME	ME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	:	QUALITY POIN	ITERS	
1		Offline	Table Lay-out	TABLE LAY-OUT Connector 6098-3803 (B)/					The second or to the se	Safety Instruction Be sure to weat prescribed person protective equipmed during operation (gloves, finger coeffice)	r nal ent n ts, Docume 1. Refer	Document reference/s: 1. Refer to WI-PRO-CNC-017 for Wire and Strip Length tolerance.		
				Connector box Irrax A Rope-Lay 0.3 wires B L=177 Assy par				parts	Housekeeping 1. Maintain and alw practice 5's. 2. Personal things the work place i prohibited. Keep ii your locker.	ays 1. No miss on 2. No exce	No missing parts/tools No excess parts/tools			
				Insertion jig CHECK BEFORE YOU INSERT Locking jig					Alert level For any trouble, inf the Assembly Assis Supervisor or Lir Leader for immedi corrective actior	stant ne ate				
					Revision History					Prepared by	Reviewed by	Approved by	Noted by	
06/06/24	4 I	Inclusion	of Measurement and improved	d Visual Inspection.			L. Ariola	C. Villanueva	A. Arañes r	n/a		,	•	
06/27/23	3 (Inclusion of Table lay-out and Quality checkpoints; improvement of important reminders/note/s and document references; Change process name from Kitting assembly to Offline assembly.												
06/12/21				17. 75.			71.	rañes Much	Jour House	900				
12/12/20	1 F	Remove cycle time, change 2x pulling to pull-push-pull-push in insertion process J. Loterte Peñaloza Shimamura						rañes L. Arjøla						
Eff. Date	Rev No	Details of Change Revised Reviewed Approved					Approved No	oted Est. Date:	May 15, 2020					



			WORK INS	Effectivity Date:	June 6, 2024					
		Process Name/Title:	OFFLIN	Validity Date:	n/a					
						TOYOTA-VITZ	Document No.: WI-ENG-PE			24
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPF	RO	Revision No.:	4	Page No.:	3 of 6
PARTS: 1. IRF		AX A Rope-Lay 0.3 wires B	JIG:	1. Insertion jig						
NO.	F	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(QUALITY POIN	TERS
3	Offline	Wire insertion to connector 6098-3803 (B)	1. Get the first black wire and insert to conduct one by one insertion from left to conduct one by one insertion f	connector using right hand to right.	2nd black wire a	2 Black R R and insert to connector	n/a	1. Make inserted Conductinsertion Do not e 2. Pleast during in Docume 1. Refer push pro	t Pull-Push-Pull-F n. xert extra force. e hold the wire ne nsertion. nt reference/s: to GL-PRO-ASY-(operly Push after Par terminal

			WORK INST	Effectivity Date:	T	June 6, 2024				
		Process Name/Title: OFFLINE ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	400B / 7M0596-7020B	Customer: TRJ	Car Model:	TOYOTA-VITZ	Document No.:		WI-ENG-PDE	-124
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	4	Page No.:	4 of 6
PARTS: 1. Ass		sy parts					JIG:	1. Locking jig		
NO.	F	PROCESS NAME	WORK PI	TOOLS/PPE	,	QUALITY POI	NTERS			
4	Offline	Connector lock	1. Load the connector into the jig holing be side of the connector, tip first. Right thumb-Lower Left thumb-middle 3. Press the lower parts of connector usin hand while left hand holding the middle. Load the connector into the jig holing be side of the connector, tip first. Right thumb-middle Report Repo	2. Press the into the locking right 4. Press the	Right thumb- Left thumb- upper part of core ft hand holding to	nnector to fully insert R pupper middle nnector using right the middle.	LOCKING JIG	1. Use the 2. No unlo Important 1. Manual lock. Documen 1. Refer to verification	provided jig per ck/half-locked co reminders and locking may can the reference/s: OGL-PRO-ASY-on. BEFORE PRES	Note/s; nuse damaged 017 for locking sSING

