
PARTS: 1.Assy parts 2.Green tape NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS TABLE LAY-OUT Safety Instruction Be sure to wear prescribed personal procetive equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is a long parts/tools and the workpla				Effectivity Date:	May 15, 2025			
PARTS: 1.Assy parts 2.Green tape JIG: 1.Clamp Assembly Jig NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS TABLE LAY-OUT Safety Instruction Be sure to wear prescribed personal protective equipment (gloves, finger cots, etc.) **Table Lay out** 1		Process Name/Title:	CLAMP ASSEMBLY P	Validity Date:	n/a			
PARTS: 1.Assy parts 2.Green tape NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS TABLE LAY-OUT Safety Instruction Be sure to wear prescribed personal proscribe depresonal current during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is a label and the workpla		Model code/Part number:	400D / 7L0161-7020 Customer: TR	Document No.:	WI-ENG-PDE-1264			
NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS TABLE LAY-OUT Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is a new report livede.		Purpose:	☐ PROTOTYPE ☐ PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	1 of 4
Table Lay out	PARTS : 1.A 2.G	.Assy parts 2.Green tape		JIG:	1.Clamp Assembly Jig			
Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is a long parts/tools and the workplace is a long parts/tools.	NO.	PROCESS NAME	WORK PROCEDURE/ ILLI	TOOLS/PPE	TOOLS/PPE QUALITY POINTERS			
your locker.		Clamp Table Lay out	TABLE LAY-O	Clamp Assembly Jig	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.	1.No missin	g parts/tools	
Revision History Reviewed by App				Green tape	For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	Checked by Reviewed by Approved by		
2000	05/15/25 0 Initia	nitial issue		A.Buban n/a C.Villanueva A	/ 1/	n/a	C.Villanueva	A.Aranes
Eff. Date Rev. No Details of Change Revised Checked by Reviewed by Approved by Est. Date: May 15, 2025	Eff. Date Rev. No		Details of Change	Revised Checked by Reviewed by Appl				710 110100

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

	_	WORK INSTRUCTION Effectivity Date:				May 15, 2025			
		Process Name/Title: CLAMP ASSEMBLY PROCESS			Validity Date:	n/a			
		Model code/Part number:			Document No.:	WI-ENG-PDE-1264			
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	2 of 4
PARTS:	1.Assy 2.Gree					JIG:	1.Clamp assembly jig		
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS		
2	Clamp	Spot Taping	CONNECTOR SETTING Receiver base 1 1. Get the assy parts and set to teste (See above picture for correct sett 3802 (W) to Receiver base 1 then lo harness, last set the B-B wires toget then press by toggle clamp. Continue location 1 was ON. 2. Check if the Clamp is ON. Check if was ON. If encountered abnormality, CALL the attention of the leader. WAI then continue the process.	er jig using both hands. er jig using both hands. ering). First, set the 6098- ck. Continue to set the ther within the stopper jig the if the sequence light in the sequence	Stopper Switch Ass	right hand then conduct ion 1. Make 3 windings on using right index finger.	Docum 1. Refer assemb Owarim 1. No flip-ou 2. No peel-o 3. No loose 4. No missin	nent reference, to WI-PRO-ASY by Hatsumono,N ono It tape ff tape tape g tape g use of tape dimension	/s: -056 for sub-

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.




CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC						Effectivity Date: Validity Date:		May 15, 2025	
		Model code/Part number:	400D / 7L0161-7020	Customer: TRQSS		Document No.:		n/a WI-ENG-PDE-1	264
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	4 of 4
PARTS:	Assy Pa	arts				JIG:	n/a		
VISUAL INSPECTION/ QUALITY CHECKPOINTS									

CLAMP ASSY

7L0161-7020



1 No Missing and No Wrong used of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.