

			WORK INSTRUCTION									tivity Date:		June 27, 2024		
			Process Name/Title: CLAMP ASSEMBLY PROCESS								Valid	Validity Date: n/a				
			Model code/Part number:	241B	/ 7L0050-7023	Customer:	TRQSS	Car Model:	LEX	KUS ES	Docu	ment No.:		WI-ENG-PDE-897	7	
			Purpose:	PROT	ОТҮРЕ	PRE-LAUNCH		MASSE	PRO		Revis	sion No.:	0	Page No.:	1 of 5	
PARTS:		1. Clamp 82711-52090 (W); Black Tape; Sample parts								JIG:	1. Clamp a	Clamp assembly jig				
NO	Ο.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION								TOOLS/PPE		QUALITY POINTERS				
1		Clamp Assy  Table Lay-out  Table Lay-out  Table Lay-out  Tape holder/ Black tape						ample parts	p (	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.						
	Į.	Revision History Prepared by								Reviewed by	Approved by	Noted by				
06/27/24	0	Initial issu	ie. Transfer Clamp process to fr	om tapina Assemh	oly process to Clamp Assembl	ly Process.		A.Hernandez	C. Villanueva	A. Arañes	n/a	ORIM CM DIA	South form	Astronom	n/a	
Eff. Date					ls of Change	,		Revised	Reviewed	A. Aranes Approved	Noted	Est. Date:	June 27, 2024	/ A. ALAUDO	II/a	
Totalia di Granigo Totalia Paris I Totalia Par																

				WORK IN	STRUCTION				Effectivity Date:		June 27, 2024	
		Process Name/Title:		CLAN	Validity Date: n/a							
		Model code/Part number:	241B	/ 7L0050-7023	Customer:	TRQSS	Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-897	
		Purpose:	□PRO	TOTYPE	PRE-LAUNCH		MASSPRO		Revision No.:	0	Page No.:	2 of 5
PARTS:	1. Clan 2. Blac	np 82711-52090 (W) k tape							JIG:	1. Clamp a	ssembly jig	
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	QUALITY POINTERS		
2	Clamp Assy	Clamp Setting	do d	1. Get 1pc of clamp 8271 location 1 using both hard  2. Get Black tape using rusing both hands.	nds.	g right hand a	and set to clam		n/a	2. No dama 3. No wron 4. No miss  STANE  On  Importa 1. Please start of a: clamp. 2. Must b and stopp	e wind for under  nt reminders/Nc e check the Clamp essembly to avoid v	tape  ote/s: first before vrong use of terminal

			Effectivity Date:	June 27, 2024								
		Process Name/Title:	Validity Date:	n/a								
		Model code/Part number:	241B	/ 7L0050-7023	Customer	TRQSS	Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-89	7
		Purpose:	PROTO	TYPE	PRE-LAUN	СН	MASSPRO		Revision No.:	0	Page No.:	3 of 5
PARTS: 1. Assy parts								JIG:	1. Clamp a	assembly jig		
NO	PROCESS NAME WORK PROCEDURE/ ILL LISTRATION							TOOLS/DDE		OLIALITY BOIN	TEDS	





Process Name/Title: Model code/Part number: Purpose:	WORK INSTRUCTION CLAMP ASSEME 241B / 7L0050-7023 Customer  PROTOTYPE PRE-LAUNC	TRQSS Car Model:	LEXUS ES	Effectivity Date: Validity Date: Document No.: Revision No.:	0	June 27, 202. n/a WI-ENG-PDE-89 Page No.:	
PARTS: n/a		LUTY OUTOVDONTO		JIG:	n/a		
		ALITY CHECKPOINTS					
CLAMP ASSY	<b>7</b> L	<u>-0050-7</u>	7023				
GOOD  NO GOOD  1 No Unlock/ Half  2 No Wrong Inser		Terminal Backir Missing Clamp	_	No Missing 1		NO C	GOOD