
WORK INSTRUCTION								Effectivity Date:		April 4, 2024		
			Process Name/Title:	CLAMP	ASSEMBLY PROC	ESS		Validity Date:		n/a		
	-1		Model code/Part number:	200D/220D / 7R0123-7023	Customer: TRMX	Car Model: TOYOT	A-SEQUOIA	Document No.:		WI-ENG-PDE-8	864	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	1 of 6	
PARTS:		1. Assy	parts; Clamp 82711-3449	0 (B); White tape				JIG:	1. Clamp A	Clamp Assembly jig		
NO	Ο.	Р	ROCESS NAME	WORK PI	ATION		TOOLS/PPE	(QUALITY POINTERS			
1	Table Lay-out Assy parts Clamp Assy Clamp assembly jig						B)/ FLAT CE)	Safety Instruction Be sure to wear required personal protective equipmen during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things of the workplace is prohibited. Keep it ir your locker. Alert level For any trouble, infort the Assembly Assista Supervisor or Line Leader for immediate corrective action.	1. No miss 2. No exce	ment references: to WI-ENG-PDE-ty process sing parts/tools. ess parts/tools.	362 Taping	
				Revision History				Prepared by	Reviewed by	Approved by	Noted by	
								 				
04/04/24		Initial issu Separate Quality ch			nprove assembly jig. Change	D.Castillo C.Villanueva		n/a Castillo	/onf/):/for- C. Villanueva	A. Areries	n/a	
Eff. Date	Rev. No			Details of Change		Revised Reviewed	Approved No	oted Est. Date: A	pril 4, 2024			

			WORK INSTE			Effectivity Date:		April 4, 2024	
		Process Name/Title:	CLAMP	Validity Date:		n/a			
		Model code/Part number:	200D/220D / 7R0123-7022	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-86	4
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6
PARTS:	1. Clan	np 82711-34490 (B)				JIG:	1. Clamp a	assembly jig	
NO.	Р	ROCESS NAME	WORK PR	OCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	C	QUALITY POINT	ERS
2	Clamp Assy	Clamp Setting	1. Get 1pc of band clamp 82711-3 using both hands.	82711-34490 (B) 4490 (B) using right hand a	and set to clamp location (1)	n/a	1. Please before st wrong us 1. No dam 2. No wror 3. No wror 4. No miss	BAND CLAMP ILLUSTRAT	first avoid

			WORK INS	STRUCTION		Effectivity Date:		April 4, 2024	
		Process Name/Title:	CLAN	IP ASSEMBLY PROC	CESS	Validity Date:		n/a	
		Model code/Part number:	200D/220D / 7R0123-7022	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-86	64
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 6
PARTS:	1. Assy	•				JIG:	·	ssembly jig	
NO.	F	ROCESS NAME	TOOLS/PPE	QUALITY POINTERS					
			STOPPER SWITCH AT IMPLY 7R0123-7023 NBC 2	32711-34490 (B)	CONNECTOR SETTING RECEIVER BASE 1 WHITE TAPE/ TAPE HOLDER			e sue no gap betw minal.	
3	Clamp	Clamp Assembly	1. Get the assy parts and set to jig usin the connector 6098-6663 (B) in Receiv harness then last, set the B-B wires to if the sequence light of location 1 was 0 2. Check if LED light for POWER, CLA STOP the process, CALL the Leader at the content of the cont	wer base 1 then lock using rig gether within the stopper the DN. MP,and SEQUENCE LIGHT and WAIT for instruction.	ght hand. Continue to set the en press by Toggle clamp. Continue T is ON. If encountered abnormality, d clamp 82711-34490 on clamp	.,,	2. No wron 3. No Loos	g setting of clamp g use of clamp e attachment of cla g setting of Bando BAND CLAMP ILLUSTRA NG 1490 (B) 8271	gun

			WORK INSTRUCTION							April 4, 2024			
		Process Name/Title:	CLAMI	P ASSEMBLY	' PROCE	ESS		Validity Date:		n/a			
		Model code/Part number:	200D/220D / 7R0123-7022	Customer: 1	ΓRMX	Car Model: T	OYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-8	64		
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO)	Revision No.:	0	Page No.:	4 of 6		
PARTS:	1. Assy	parts						JIG:	1. Clamp a	assembly jig			
NO.	P	ROCESS NAME	WORK P	ROCEDURE/ IL	LUSTRA	TION		TOOLS/PPE		QUALITY POIN	TERS		
3	Clamp	Clamp Assembly (Continuation)	-1-0-1-0	BANDO GUN ALIGNMENT NG OK PERPENDICULARITY	5. Get the cut the baboth hand GO soun 6. Condu	4. Get start ta using b winds). button process light on ON.	ECKING before	BANDO GUN FLAT NOSEPIECE	Importa 1. Make and term GOOD S271 1. No wror 2. No wror 3. No Loos 4. No wror BAN	BAND CLAMP ILLUST	ration Idamp Igun Igu		




ĺ			WORK INSTRUCTION						Effectivity Date:		April 4, 2024	
			Process Name/Title:	C	Validity Date:		n/a					
			Model code/Part number:	200D/220D / 7R0123-	7022	Customer: TRM)	Car Model:	TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-8	64
]			Purpose:	PROTOTYPE		PRE-LAUNCH	MASS	PRO	Revision No.:	0	Page No.:	6 of 6
ĺ												
	PARTS: 1. /		1. Assy parts					JIG:	n/a		ļ	

VISUAL INSPECTION

CLAMP ASSEMBLY

7R0123-7023



1 No Loose clamp

2 No NG cut

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.