					Effectivity Date:	June 3, 2024					
		Process Name/Title:		WORK INSTRUCTION TAPING ASSEMBLY PROC	Validity Date:	n/a					
		Model code/Part number:	700B /	<b>7N0039-7020B</b> Customer: <b>TRJ</b>	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-88	33B		
		Purpose:	☐ PROTOTYP	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	1 of 6		
							1				
PARTS:	1. Assy	parts; Black corrugated tul	JIG:	n/a							
NO.	P	ROCESS NAME		TOOLS/PPE	(	QUALITY POINTERS					
1	P2	Table lay-out	Assyp	TABLE LAY-OUT  Table Lay-Out  Tape holder/Black tape	Black corrugated tube (no slit) ø5 L=496±4mm	Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.		ing parts/tools iss parts/tools			
	•	<u> </u>		Revision History		Prepared by Re	eviewed by	Approved by	Noted by		
06/03/24 1	Change r	pre-launch to mass pro.			A.Hernandez C. Villanueva A. Arañes	n/a Ohmander	long Tilloum	1			
05/09/24 0	Initial Iss						Villanueva	A. Arañes	n/a		
Eff. Date Rev. No	)		Details of C	Change	1 1 1		9, 2024				
•					·		•	-			




WORK INSTRUCTION Effectivity Date: June 3, 2024										
		Process Name/Title:	TAP	ING ASSEMBLY PROC	ESS	Validity Date:	n/a			
		Model code/Part number:	700B / 7N0039-702	OB Customer: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-88	3B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 6	
	1. Assy 2. Blac	parts k corrugated tube ø5 L=496	6±3mm (No Slit)	3. Black tape	JIG:	1. Terminal cover jig				
NO.	F	PROCESS NAME	WORK	( PROCEDURE/ ILLUSTR.	ATION	TOOLS/PPE	QUALITY POINTERS			
2	P2	Spot taping	1. Combine the assy parts then align all terminals.  L Start of taping  3. Get the Black tape using right har then conduct 2 windings of spot taping using both hands.	2. Conduct measurement ip 100±3mm using bo	80±3mm		Impoi 1. Plea measu measu 1. No flip-ou 2. No peel-o 3. No loose 4. No missir	rtant reminders/N use use calibrated uring tape when g urement.  It tape tift tape tape tape tape tape tupe tape tupe tape tupe tupe tupe tupe tupe tupe tupe tupe	ote/s:	
3		Wire insertion to Black corrugated tube (no slit) ø5 L=496±4mm	1. Hold the wires using left hand, get the terminal cover jig using right hand then insert the B-G-V wires using left hand.	2. Get the corrugated tube (no slit) ø5 L=496±3mm (no slit) using right hand then insert the B G-V wires using left hand.	3. After insertion, remove the	Terminal cover Jig	1. No wrong 2. No deform	insertion ned terminal		

NBC (Philippines)
MASTER COPY

				WORK INST	June 3, 2024							
		Process Name/Title:		TAPING	ESS	Validity Date:	n/a					
		Model code/Part number:	700B /	7N0039-7020B	Customer:	TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-883	3B	
		Purpose:	PROTOTY	PE	PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	3 of 6	
PARTS:	1. Assy 2. Black	k tape						JIG:	n/a			
NO.	P	PROCESS NAME		WORK PR	ROCEDURE/ IL	LUSTR	ATION	TOOLS/PPE	QUALITY POINTERS			
4		Wire insertion to Black corrugated tube (no slit) ø5 L=496±4mm (Continuation)	6 7	8 9 GU 1	39±3mm 11111111111111111111111111111111111	( post	4. Conduct measurement between end of COT up to pointed tip 39±3mm.	6 7 8 9 10 1 2 3 4 5 6 7 8 9	Importa	med terminal  ont reminders/Note  use calibrated/veng tape when gett	erified	
5	P2	Y-Taping	Note: Do not exert exceduring pulling & tape.	winding of	tape s 1/2 I	shifting below	2. Hold two SV tubes (Vinyl) and left hand and fix to COT. Make 1 winding for pre-tape before shifting then wind the tape down to SV tube (Vinyl) until tape width.	MEASURING TAPE  6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	Importar  1. Use YI visualiza actual sh  2. Please	off tape e tape ing tape g dimension g use of tape  out reminders/Note  ELLOW tape to eation of shifting limite to be a shifting limited limit	nsy nes, but TAPE. erified	

NBC (Philippines)
MASTER COPY





	WORK INSTRUCTION								June 3, 2024			
		Process Name/Title:		TAPING	Effectivity Date:  Validity Date:							
		Model code/Part number:	700B /	7N0039-7020B			odel: TOYOTA-LAND CRUISE			WI-ENG-PDE-88	3B	
		Purpose:	□PROTOTY		PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	5 of 6	
PARTS:	n/a							JIG:	n/a			
NO.	P	ROCESS NAME		WORK P	ROCEDURE/ II	LUSTRATIO		TOOLS/PPE	QUALITY POINTERS			
6	P2	Measurement	② 39±3  1 0 0 0  NOTE: ③ - Taping (8) ③ - Taping (G)		((((((((((((((((((((((((((((((((((((	Van	E TABLE	White  White  White  S 25 ±3  S 25 ±3  Winyl Tube(8) Ø5	1. Please measuring measurer 2. For Ha Owarimon  Docume 1. Refer to assembly Owarimon	tsumono, Nakamor	fied g the no and for Sub-	




NB			WORK INSTRI	Effectivity Date:	June 3, 2024							
		Process Name/Title:	TAPING A	Validity Date:	n/a							
		Model code/Part number:	700B	1	7N0039-7020B	Customer:	TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-88	33B
		Purpose:	□PR	ОТОТҮР		PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	6 of 6
PARTS:	n/a								JIG:	n/a		
	.,,									.,,		

VISUAL INSPECTION/QUALITY CHECKPOINTS

**P2** 

## 7N0039-7020B



- No Missing spot tape)
  (on wire taping)
- 2 No Missing Tape (on Y-taping)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY