
									Effectivity	Date:		April 23, 2025		
			Process Name/Title:	Name/Title: CLAMP ASSEMBLY PROCESS					Validity Da	ite:		n/a		
			Model code/Part number:	559D / 7N0238-7020C Customer: TRJ Car Model: TOYOTA HIGH-AC				Document No.:			WI-ENG-PDE-1226			
	<u></u>		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	ا	MASSPRO		Revision N	lo.:	0	Page No.:	1 of 5	
PARTS:		1. Assy parts 2.Clamp 82711-16830 (B) 3.Clamp 82711-52090 (W)		4.Clamp 82711-16820 (BR) 5. Black tape [2 pcs.] 6. Brown tape					JIG:		Temporary Assembly jig Bando Gun			
NO.		PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TC	OLS/PPE	(QUALITY POIN	TERS		
1				WORK PROCEDURE/ ILLUSTRATION 82711-16830 (B) 82711-52090 (W) 82711-16820 (BR) 1. Get 1pc. of clamp 82711-16830 (B) using right hand and set to clamp location 1 using both hands. 2. Get 1pc. of clamp 82711-52090 (W) using right hand and set to clamp location 3 using both hands. 3. Get 1pc. of clamp 82711-16820 (BR) using right hand and set to clamp location 3 using both hands.				Be sure perso equi operati I. Maii p 2. Perso workpla Keep i For any the Ass Supervis	ty Instruction to wear requirement during on (gloves, fing cots, etc.) """ usekeeping ntain and alwa aractice 5's. onal things on tace is prohibite it in your locke """ usekeeping ntain and alwa aractice 5's. onal things on tace is prohibite it in your locke """ usekeeping ntain and alwa aractice 5's. onal things on tace is prohibite it in your locke """ usekeeping ntain and alwa aractice 5's. onal things on tace is prohibite it in your locke """ usekeeping ntain and alwa aractice 5's. onal things on tace is prohibite it in your locke	2. No wron 3. No dam 4. No wron 1. Pleas before wrong the ed. ir.	Important reminders/Note/s: 1. Please check the Clamp first before start of assembly to avoid wrong use of clamp.			
	Revision History Prepared by Checked by Reviewed by Approved by													
04/23/25		Initial iss	ue			-	Hernandez J.Lotert	A./		INCM du/ .Hernandez/	J.Loterte		A.A.a.des	
Eff. Date Rev. No Details of Change Revised Checked Reviewed Approved Est. Date: April 23, 2025														

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.


NBC (Philippines)

MASTER COI


MASTER COPY



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.




CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			Effectivity Date:	April 23, 2025					
		Process Name/Title:	CLAMP	Validity Date:	n/a				
		Model code/Part number:	559D / 7N0238-7020C	Customer: TRJ	Car Model: TOYOTA HIGH-ACE	Document No.:	WI-ENG-PDE-1226		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	☐ MASSPRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	1. Assy	parts	JIG:	n/a					

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7N0238-7020C



- 1 Check the Clamp Alignment
- 2 No Missing Tape/Spot Tape (Black/Brown)
- 3 No Wrong Used of Tape
- 4 No Missing Clamp

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.