

			WORK INSTRUCTION							May 21, 2024		
			Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:		n/a		
			Model code/Part number:	310D / 7N0189-7020A	Customer: TRJ	Car Model: TOY	OTA RAV4	Document No.:		WI-ENG-PDE-798		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	2	Page No.:	1 of 4	
PARTS:		1. Assy parts; Black SV tube (vinyl) ø5 t=0.5 L= 129±3mm; Pink Tape						JIG:	n/a	n/a		
NO.		PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS			
		P1	Table Lay-out		Tape holder / Pink tape	Black SV tube (ø5 L=129±3n		Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistan Supervisor or Line Leader for immediate corrective action.	Docum 1. Refer Strip Ler 1. No missi 2. No exces	nent reference/ to WI-PRO-CNC-to gdh Tolerance ng parts/tools ss parts/tools	s:	
Revision History Prepared by Reviewed by Approx											Noted by	
05/04/6:		Split type process. Transfer wire insertion to connector to offline process and inclusion of table lay-out. A Harmandaz C Villanulus A Arañes						n/a				
05/21/24 03/06/24		Antenandez Ormandez Ormandez						O O O O O O O O O O O O O O O O O O O				
02/13/24		Antenianuez					1 1	/a Utuni Con Joseph Jos			n/a	
Eff. Date	Rev. No	Details of Change				Revised Reviewed			bruary 13, 2024	,		





NBC (Philippines)
MASTER COPY



NBC (Philippines)
MASTER COPY



NBC (Philippines)

MASTER COPY