488	-	Process Name/ Title:						
	T	Wire Cutting and Crimping / How to Use Oil Remover Machine WORK INSTRUCTION		Document No:		WI-PRO-CNC-020		
	A			Effective Date:		July 10, 2017		
	NO SE	Product Code/Name:	Customer Code:	Rev. No.:	n	Page No.:	Page 1 of 1	
		ALL	ALL	1101.110	v	1 age 140	rage rorr	

	ALL ALL Nev. No V Page No	- rage 1011
No.	Work Procedure/ Illustration	Records/Remarks/ Quality Pointers
	How to use Oil Remover Machine	
	TOW to use of Remover Magnine	
	1. Perform Machine Checking, use Machine Daily Checksheet.	F-PRO-CNC-013
	2. Turn machine ON. Pull the knob then raise the handle to open.	
	Handle	
	Knob	
	Switch ON / OFF	
	Sincer ext, etc.	
	S= 1 min.	
	Timer M= 2 min. L= 3 min.	
	2 3	
	3. Check the basket. It must be empty.	
	In case there is leftover seal on the basket, remove and scrap it.	
	4. Put waterproof seal to be drained inside the basket.	
	5. Close the cover. Pull the knob to lock.	
	6. Press Start. 7. After finishing, open cover, get basket then remove waterproof seal.	
	Make sure there no seal is left inside the basket.	
	8. Put basket back to the machine, close cover, pull knob to lock. 9. Turn machine OFF.	
	5. Turn machine orr.	
	Note:	
	in Note: If there is any possibility that another waterproof seal is mixed, scrap all the seals.	
	NBC (Philippines)	
	MASTER COPY	
	Prepare	Check Approv
	Trippine On Q	The state of the s
	NBCP-1223 NA Previously established Work Instruction(for history purpose only) 2. Mendez	O.MERIN T. SUGIYA
ff./Rev.Date	Doc/DRCN No. Rev. No.(if applicable) Details of change Revise Check Approve Est. date:	07/10/2017