WORK INSTRUCTION Effectivity Date: February 7, 2025										05
			Process Name/Title:	Validity Date:	n/a					
			Model code/Part number:	524D / 7N0241-7020	MP ASSEMBLY PROC	Car Model: TOYOTA-PROBOX		WI-ENG-PDE-1189		
					l .		-	_	1	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 5
PARTS:		1. Assy parts; Clamp 82711-52090 (W); Black tape [2pcs]; Violet tape						1. Clamp as	sembly jig	
N	0.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POIN	TERS	
	1	Clamp Assy	Table lay-out		TABLE LAY-OUT	GWGT ASSEMBLY NBC	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	2. No wrong 3. No dama 4. No wrong 5. No loose 6. One by o 7. No deforr 8. No wrong Import 1. Make s inserted. Push afte Do not ex 2. Please Docume 1. Refer and Strip	ne insertion ned terminal wire facing ant reminders/No sure wires are pro Conduct Pull-Puer insertion. kert extra force. hold the wire ne ent references: to WI-PRO-CNC-to length tolerance to GL-PRO-ASY-to	ote/s: operly ish-Pull- oar terminal 017 for Wire e.
Revision History							Prepared by	Reviewed by	Approved by	Noted by
						+ + + + + + + + + + + + + + + + + + + +				
02/07/25		Table lay-out; Visual Inspection/Quality Checkpoints.							n/a	
Eff. Date	Rev. No			Details of Change		Revised Reviewed Approved No	oted Est. Date: Febr	ruary 07, 2025		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COF


MASTER COPY

WORK INSTRUCTION Effectivity Date: February 7, 2025										
		Process Name/Title:	CLAN	Validity Date:			n/a			
		Model code/Part number:	524D / 7N0241-7020	Customer: TRJ	Car Model: TOYOTA-PROBOX			WI-ENG-PDE-11	189	
		Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	2 of 5	
PARTS:		p 82711-52090 (W) [3pcs] tape [2pcs] tape			JIG:		1. Clamp assembly jig			
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POINTERS		
2	Clamp Assy	Clamp setting	1. Get the 2pcs of clamp 82711-5209 then set to clamp location 1 and 2 us 2. Get the 1pc. of clamp 82711-5209 then set to clamp location 3. using both the set to clamp location 3. using both the set to clamp location 3.	o (W) using right hand	3. Initially attach the VIOLET TAPE to both hands. 4. Initially attach the BLACK TAPE to both hands.	o Clamp location 3 using	1. Pleas start of of clam 1. No loose 2. No dam 3. No Miss	e attachment of cla aged clamp ing parts. One wind for under	np first before id wrong use	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

		WORK INSTRUCTION Effectivity Date:						February 7, 2025		
		Process Name/Title:	CLAN	OCESS	Validity Date:		n/a			
		Model code/Part number:	524D / 7N0241-7020	Customer: TRJ	Car Model: TOYOTA-PROBOX	Document No.:		WI-ENG-PDE-1	189	
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 5	
PARTS:	Assy parts Black tape [2pcs] Violet tape [1pc]				JIG:			Clamp assembly jig		
NO.	PROCESS NAME		WORK	PROCEDURE/ ILLUS	STRATION	TOOLS/PPE	(QUALITY POINTERS		
3	Clamp Assy	Clamp assembly		d Wire 2 was ON. If immediately CALL urther instruction and light on location 1 was LACK TAPE using using both hands then ter taping. Continue the		Stopper jig O2 (W) into Checker 1. jig then press by the K TAPE using right hand. is then cut the tape. ue the process if the ET TAPE using right hands then cut the GO buzzer will be heard.	2. No wrong 3. No dama 4. No wrong Import 1. Make stopper 2. Make taping. Import 1. Pleasi before s	use of parts use of tape ged clamp glocamp glocamp position ant reminders/ sure no gap between derminals 2-3 windings for ant reminders/Note the clamp tart of clamp assorong use of clamp	veen clamp otes p first embly to	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.




CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

		WORK INSTRUCTION				Effectivity Date:	February 7, 2025			
		Process Name/Title:	CLAMP ASSEMBLY PROCESS				Validity Date:	n/a		
		Model code/Part number:	524D / 7N0241-7020	Customer:	TRJ	Car Model: TOYOTA-PROBOX	Document No.:		WI-ENG-PDE-1	189
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	1	■ MASSPRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	n/a						JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7N0241-7020



1 No wrong facing of clamp

No Missing Tape / No wrong use of tape (Black tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.