				WORK INSTRUC	TION			Effecti	ivity Date:		May 05	, 2022	
		Process Name/Title:							Validity Date:		n/a		
		Model code/Part Number	715W	/ 7H0420W7020			NBS		Document No.:		WI-ENG-PDE-512		
					L								
		Purpose:	☐ PROTOTYPE ☐ PRE-LAUNCH		MASS	MASSPRO Revision No.:		on No.:		1 Page No.:	1 of 3		
PARTS:	1. All parts; Pre-assy parts from Offline (Connector 6098-3802 (W); IRRAX A 0.3 B wires L=140±2mm); Black vinyl tube ø5 L=70±3mm; Yellow tape										n/a		
NO.	PI	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					1	rools/	PPE	QUALITY POINTERS		
1	n/a	Table Lay-out		Black vinyl tube L=70±3mm Assy parts		Master sample		pr pro (glov	fety Instr Be sure to vescribed per tective equitoring oper ves, finger of Housekee Maintain an practice! Personal the personal the workple oblighted. Kee your lock Alert level any trouble Assembly Arvisor or Lirunmediate of action.	wear ersonal uipment ration rots, etc.) eping d always 5's. nings on ace is eep it in eer. yel n, inform assistant ne Leader orrective	No missing pa No excess par		
Ţ.				Revision History				1		Prepared by	Reviewed by Appro	ved by Noted by	
					M.Ariola	J.Loterte		A. Arañes	Interest	Jan 7			
05/02/22 0	Initial iss	ue		Astolla of Change		M.Ariola	J.Loterte		A. Arañes	M. Ariola		anueva A. Arañes	
Eff. Date Rev. No	ļ		D	Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	May 2, 2022		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

			Effectivity Date	Effectivity Date:		May 05, 2022						
		Process Name/Title: TAPING ASSEMBLY PROCESS Validit							n/a			
		Model code/Part Number	715W / 7H0	0420W7020	Customer:	NBS	Document No.	Document No.:		WI-ENG-PDE-512		
		Purpose:	☐ PROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:		1	Page No.:	2 of 3	
	1						•		1			
	1. Pre-assy parts from Offline (Connector 6098-3802 (W); IRRAX A 0.3 B wires L=140±2mm) 2. Black Vinyl tube ø5 L=70±3mm 3. Yellow tape								n/a			
NO.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					S/PPE	QUALITY POINTERS			
2		Wire Insertion to Black Vinyl tube ø5 L=70±3mm	L set	R		Vinyl tube <mark>ø5 L= 70±3mm</mark> t hand then insert the <mark>B-B</mark>	n/a	ı		ong usage of formed termii		
3	n/a	Taping 1 Black Vinyl tube to Wire near connector					ping 6 7 8 9 10 1 2 3				Note: Please use calibrated/verified measuring tape when getting the measurement. 1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

			WORK IN	Effectivity Date:	May 05, 2022		
		Process Name/Title:	TAPIN	Validity Date:	n/a		
		Model code/Part Number	715W / 7H0420W	V7020 Customer:	NBS	Document No.:	WI-ENG-PDE-512
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 3 of 3
	1					1	
PARTS:	n/a					JIG	n/a
NO.	PI	ROCESS NAME	WORK	PROCEDURE/ ILLUSTRATIO	N	TOOLS/PPE	QUALITY POINTERS
			1. Check the connector lock.	2. Check the taping condition	3. Check the terminal app deformed terminal.	earance. Make sure no	
4	n/a	Visual/By Two's inspection		4. Compare to Master Note: Please refer to G	Sample GL-PRO-ASY-007 for By Two's In	spection of Sub-	MASTER SAMPLE
5		Measurement		ASURING TAPE Note: Please use calibrate getting the measure 166±3mm	ed/verified measuring tape whe ement. 35±3mm	n	NOTE: FOR HATSUMONO AND OWARIMONO 1. No wrong dimension

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY