

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-487

April 25, 2022

WORK INSTRUCTION Product Code/Name:

Customer Code: NBS

Effective Date: Rev. No.:

			Product Code/Name 7H0402W7020A	l l	Customer Code: NBS	Rev. No	D.:	0		Page No.:	Page	e 1 of 1	
No.	Work Procedure/ Illustration										Records/Remarks/ Quality Pointers		
					Salah Wasanin					Qty/ Box	120 pcs	10pcs* 12bdls	
1	Put Vinyl Sheet (1520 x 1500)							Mat'l name	Dim.	Qty			
								Master box	535*360* 150 mm	1			
			side the box.						Vinyl Sheet	1520*1500	1		
							The second second			Partition Board	343*510	1	
								and the			300*200mm	12	
2			products. (10pcs/bdl) posite direction.						Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 7 is applicable only in QC FG Inspection.				
3	Put partition board												
4	Put 6 bdls of products. (10 pcs/bdl) in opposite direction. SAMPLE INNER TAG THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A THOMOZWY020A						r AG	Make sure that the inner tag indicates the correct terminal expiration date.					
(5)		Fold	the vinyl sheet.										
6			P Identification tag g at the left side of the box	14									
7	left s	side c	Identification tag at the of the box and NBP g in the right side of the box.	to the second	7H0402W7020A 120 120 120 120 120 120 120					Outgoing Inspectors are the person-in-charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.			
										Prepare	CHECK	Approve	
04/25/2022 Eff./Rev. Date	0 Rev. No.			Initial Details o			J. Loterte Revise	C, Villanueva Check	A. Arañes Approve	J. Loverte Est. date	C. Villanueva April 25	A. Areries 5, 2022	