Document No: WI-QAD-QAC-276 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: October 16, 2024 Product Code/Name: Customer Code/ Customer Rev. No.: Page No.: Page 1 of 1 7R0119 **TRMX** Records/Remarks/ Work Procedure/ Illustration No. **Quality Pointers** (1) 50pcs\*4 Qty/box 200 bdls Mat'l Dim. Qty. Put Vinyl Sheet name (1250 x 1250) inside TRMX box. **TRMX** 544\*370\* 1 228mm box Vinyl ∆1250\* 1 sheet 1250 (2) 343\* 50pcs × 2bdls **Partition** 1 board 510 Vinyl 420\* 4 Put the products inside 280 bag the box (opposite direction per bundle) Step 5 is applicable only in QC (50pcs\* 2 bundles) FG inspection. Plastic vinyl bag of MRSW assy 1st LAYER (3) Layout partition board (4) Put another bundles inside the box (opposite direction per bundle) (50pcs\* 2 bundles) **2ND LAYER** (5) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at right side of the box. Note: If need to attach 4M tag Put 4M tag at the left side of the box Prepared by Checked by Approved by Noted by Change control no. from WI-ENG-PDE-671 to WI-QAD-QAC-276;Change vinyl size from 1520x1500mm to 10/16/24 D. Dadulla S. Malabuyoo R. Pascua O. Merin Malabuyo 1250x1250mm. C. Villanueva 04/28/23 M. Catapang J. Loterte A. Arañes Eff. Date Rev. No. Details of change

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

Process Name/ Title:

NBC (Philippines)

MASTER COPY