

PACKING INSTRUCTION

Document No:

Effective Date:

WI-QAD-QAC-140

Customer Code:

February 28, 2024

			75N829	TRJ	Rev. No.:	2	Page No	.: Pag	je 1 of 1	
No.		Work Procedure/ Illustration						Records/Remarks/ Quality Pointers		
1	ori	Prepare empty oricon box in the "after inspection area"						400 Dim. 386*55* 243 343*510 545*450	100pcs*4bdls Qty. 1 3 4	
2	then pu harness a tag insid	nyl (plastic) bag it the 100 pcs nd place the ID e then fold the istic bag.		THE TOTAL PROPERTY OF THE PROP						
3	position ar board vert alternately products.	with the Bundles with	MI CONTROLL OF THE PARTY OF THE				Smaller white connectors must be on top position.			
<u>2</u> <u>4</u>	Put NBP Identification tag at the top then warehouse identification tag at front side of the box		* If need to attach 4M tag. Put 4M tag at the upper left side of the box.							
2/28/2024 8/12/2022 8/31/2019 Eff. Date	2 1 Update p 0 Rev. No.		Remove Vinyl Sheet product orientation based on customer requi Initial issue Details of change	M. Garcie rement M. Garcie C. Dimailie Preparec	R.Alcantara M.Lumbres	R.Pascua A.Arañes E. Mendoza Approved	Prepared M. M. Gardia Establish Date	Checked D.Dadulla	Approved Fi. Hascua	

ONFIDENTIAL: NBC; all rights reserved. Any misuse or mis appropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any infor mation herein is strictly prohibited.

Rev. No.

NBC (Philippines) **MASTER COPY** Prepared

Checked

Details of change

Approved Establish Date: August 31, 2019