				WOR	K INSTRUCTION			Effectivity Date:	<u> </u>	October 15, 20	124
			Process Name/Title:				n/a	,2			
			Model code/Part number:	380D / 7L0140-702	APING ASSEMBLY PRO OB Customer: TRQS		E TOYOTA-CAMRY	Document No.:	WI-ENG-PDE-1094A		
		<u> </u>	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR		Revision No.:	1	Page No.:	1 of 4
PARTS:			Sf 0.3 wires B-B L=684±3mm VM VM tube (Sunprene) ø5 l		GR-B/W wires L=692±3mm			JIG:	n/a		
NO	Э.	F	PROCESS NAME	W	TOOLS/PPE	(QUALITY POIN	TERS			
1		P1	Table Lay-out	Black vinyl tube (Sunprene) Ø5 L- 106mm	MR SW CP GR-B/W wires L=692±3mm AVSSf 0.3 wires B-B L=684±3mm		Black Tape / Tape Holder	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.)0 Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. No wi 2. No de Documer 1. Please for Wire	rong use of parts eformed terminal nt reference/s: refer to WI-PRO and Strip length refer to WI-ENG e Assembly Proc	-CNC-017 tolerance. -PDE- 669
				Revision H	listory			Prepared by	Reviewed by	Approved by	Noted by
10/15/24	0	Change f	rom Pre-launch to Masspro. ue.			A. Hernandez	. Villanueva A. Arañes		South House C. Villanueva	A. Aranes	n/a
Eff. Date	Rev. No			Details of Change		Revised	Reviewed Approved N	loted Est. Date: Oct	ober 14, 2024		

			WORK INST	RUCTI	ON			Effectivity Date:		October 15, 20)24
		Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:	n/a		
		Model code/Part number:	380D / 7L0140-7020B Custome		omer: TRQSS	ner: TRQSS Car Model: TOYOTA-CAMRY		Document No.:	WI-ENG-PDE-1094A		
		Purpose:	PROTOTYPE	PRE-L	AUNCH	MASSP	PRO	Revision No.:	1	Page No.:	2 of 4
PARTS: 1. AVSSf 0.3 wires B-B L=684±3mm 2.Black VM VM tube (Sunprene) ø5 L			.= 106±3mm	JIG:	n/a						
NO.	-	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(QUALITY POIN	TERS
2	P1	Spot Taping	L	R	black tape the Make 2 windir	n start tapin ngs then cut	g left hand, get ng using both hand. the tape. wire alignment and	n/a	1. Use 1 2. Plea: measus the me 1. No fli 2. No po 3. No lo 4. No m 5. No w	ant reminders/NBLACK TAPE ONI Se use calibrated ing tape when g asurement. p-out tape. p-out tape. eel-off tape. ose tape. issing tape. rong dimension. rong use of tape	. <u>Y.</u> I/verified Jetting
3		Wire insertion to Black VM tube (Sunprene) ø5 L= 106±3mm (Assy parts)	L	R	692mm) using r	ight hand th	mm , GR and BW L- nen insert to mm (Assy parts)	n/a	2. No de Docum 1. Pleas	rong use of parts eformed termina ment reference/ e refer to WI-PR ed Strip length to	l is: PO-CNC-for

			WORK INS	Effectivity Date:	October 15, 2024					
		Process Name/Title:	TAPIN		Validity Date:	n/a				
		Model code/Part number:	380D / 7L0140-7020B	Customer: T	RQSS Car Model:	TOYOTA-CAMRY	Document No.:		WI-ENG-PDE-10	94A
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSF	PRO	Revision No.:	1	Page No.:	3 of 4
PARTS:	1.Ass	/ part 2.Black Tape	9				JIG:	n/a		
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POIN	TERS
4	P1	Taping 1 Black VM tube (Sunprene) to wire near terminal and PCB	1. Hold the VM tube (Sunprene) usin hand. Measure from end of sunprenedge of hotmelted wires 80±3mm ar terminal pointed tip using right hand	e up to the and up to	3. After taping, ch	ire alignment and	6789 1234 5 5 7 8 5	2. No flip 3. No loc 4. No wr 5. No wr 6. No m	eel-off tape to out tape to se tape rong use of tape rong dimension issing tape rtant reminder se use calibrate ring tape when rement.	n rs/Note/s: ed/verified

NBC	Process Name/Title: Model code/Part number:	_	STRUCTION NG ASSEMBLY Customer: T	PROCESS RQSS Car Model:	Effectivity Date: Validity Date: Document No.:		October 15, 2024 n/a WI-ENG-PDE-1094A			
MBC	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP		Revision No.:	1	Page No.:	4 of 4	
PARTS: 1.As	ssy parts					JIG:	n/a			
		VI	SUAL INSPECTION	ON/QUALITY CHE	CKPOINTS					
T/	APING - P1			7L	0140-7	020B				
					1		2			
		g Spot Tape				3) No 1	Vissi			