

75N350

Process Name/ Title: WI-QAD-QAC-120 Document No: **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: February 28, 2024 Product Code/Name: Customer Code: Rev. No.: Page 1 of 1

3

Page No.:

No.		Work Procedure/ Illustration	Records/Remarks/ Quality Pointers		
1)	Prepare empty oricon box in the "after inspection area"		Qty/box	400pcs.	100pcs* 4bdls
			Mat'l name	Dim.	Qty.
			Oricon box	386*550* 243	1
			Partition board	343*510	3
			Plastic vinyl bag	545*450	4

TRJ

Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products 2 in same direction. Put the ID tag inside then fold the plastic bag.



\<u>3</u>

(3)

position and partition board vertically & alternately with the products. (100pcs* 4 Bundles with I.D tag inside)

Put products on vertical



White connectors must be on top position.

Put NBP Identification tag at the top.Then warehouse Identification 4 tag at lower right side of the box





Note: If need to attach 4M tag
Put 4M tag at the left side of the box

						Prepared	Checked	Approved
								1 /
2/28/2024	3	Remove Vinyl Sheet	M. Garcia	D.Dadulla	R.Pascua			/ .
8/12/2022	2	Update product orientation to standing position	M. Garcia	R. Alcantara	A. Arañes	mensfilm	Mua	ML
8/03/2021	1	Update location of tags in step number 5 and remove revision number	C.Dimailig	M.Lumbres	E. Mendoza	1 / E / X Julie	(Cure I	11 1/ 0
4/17/2019	0	Initial issue	C.Dimailig	M.Lumbres	E. Mendoza	M. Garcia	D.Dadulla	R Pascua
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Establish Date: Ápril 17, 2019		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any orm, disclosure or publishing of this document or any information nerein is strictly prohibited.

NBC (Philippines) MASTER COPY