PARTS:  1. All parts: Connector 6188-0066 (GR); AVSSI Y-OR L=364-2mm; Black corrugated tube e7 L=45-3mm (No siti); Black corrugated tube e5 JiG; 2. Insertion jig with switch correct 2. Insertion jig with switch with switch correct 2. Insertion jig with switch correct 2.	WORK INSTRUCTION Effectivity Date: April 30, 2024													24			
PARTS:  1. All parts: Connector 6188-0066 (GR); AVSSI Y-OR L=364-27mm; Black corrugated tube of L=45:3mm (No sit); Black corrugated tube of L=265:4mm (No sit); Connector 6188-0066 (GR); AVSSI Y-OR L=364-27mm; Black corrugated tube of L=265:4mm (No sit); Connector 6188-0066 (GR); Connector 6188-0066 (GR)  PROCESS NAME  WORK PROCEDURE! ILLUSTRATION  TABLE LAY-OUT  Black corrugated tube of L=265:4mm (No sit)  Black corrugated tube of L=265:4mm (No sit)  TABLE LAY-OUT  Black corrugated tube of L=265:4mm (No sit)  Connector 6188-0066 (GR)  AVSSI OR L=3842mm  Connector 6189-1161 (B)  Connector 6188-0066 (GR)  AVSSI Y L=3642mm  Connector 6189-1161 (B)  Locking jig  Document references:  1. Refer to Wi-PRO-CNC-017 for Winsing parts/holds. Keep it in your locker.  All parts (Connector first)  Locking jig  Revision Fiscory  Revision Fisco				Process Name/Title:		OFFLINE ASSEME	BLY PRO	CESS			Validi	ty Date:			n/a		
1. All parts: Connector 6188-0066 (GRY). AVSSI Y-OR L=364-2mm; Black corrugated tube of L=45-3mm (No siti); Black corrugated tube of Sub-tife (R)  NO. PROCESS NAME  WORK PROCEDURE/ ILLUSTRATION  TABLE LAY-OUT  Black corrugated tube of L=4523mm (No siti)  TABLE LAY-OUT  Black corrugated tube of L=2623mm (No siti)  Table Lay-out  Connector 6188-0066 (GRY)  Connector 6188-161 (R)  Connector 6188-0066 (GRY)  AVSSI Y L=36422mm  Connector 6188-161 (R)  Insertion jig a  Revision Flation  Results to wear protection equipment for protection of protect		-		Model code/Part number:	930B /	<b>7N0204-7020Ca</b> Customer:	TRJ	Car Model:	TOYOT	4-4 RUNNER	Docu	ment No.:			WI-ENG-PDE-	379	
PARTS: L'Al gabrier (1997) (2016) (1997) (19				Purpose:	PROTOTYPE	PRE-LAUNC	Н	MASS	PRO		Revis	ion No.:		1	Page No.:	1 of 9	
TABLE LAY-OUT  Black corrugated tube of L=268±4mm (No sit)  Connector 6188-066 (GRY) Connector f188-066 (GRY) Connector f189-1161 (B) Connector f189-1	PARTS:	L=266±4mm (No slit); Connector 6189-1161 (B)											2	2. Insertion 3. Locking ji	jig ig		
Black corrugated tube of L=3654mm (No sit)  Black corrugated tube	NC	Э.	Р	ROCESS NAME		WORK PROCEDURE	/ ILLUSTR	ATION				TOOLS/PPE		QUALITY POINTERS			
1 Offline   Table Lay-out   Connector 6188-0066 (GR)/ Connector tray   Connector 6189-1161 (B)/ Connector tray   Insertion jig A   AVSSf Y L=364±2mm   Connector tray   AVSSf Y L=364±2mm   Connector tray   Insertion jig A   Avssistant Supervisor or Line Leader for immediate corrective action.   Approved by Approved b				ine Table Lay-out	Black L=4	Black corrugated tube ø7  Black corrugated tube ø5						Be sure to wear prescribed personal protective equipment during operation					
AVSSf Y L=364±2mm  Insertion jig B  Locking jig  Revision History  Prepared by Reviewed by Approved by Noted to Corrective action.  D.Castillo C. Villanueva A. Arañes n/a O4/26/24 0 Initial issue  D.Castillo C. Villanueva A. Arañes n/a D.Castillo C. Vill	1	ı	Offline		Connec	R L=364±2mi	Connector 6189-1161 (B)/			1. i 2.	Maintain and always practice 5's.     Personal things on the workplace is prohibited. Keep it in		Refer to WI-PRO-CNC-017 for Wire an Strip length tolerance.      No missing parts/tools				
Revision History  Prepared by Reviewed by Approved by Noted to Masspro.  D.Castillo C. Villanueva A. Arañes n/a  O4/26/24 0 Initial issue  D.Castillo C. Villanueva A. Arañes n/a										For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate		orm tant e ate	n				
04/30/24 1 Change from Pre-launch to Masspro.  D.Castillo C. Villanueva A. Arañes n/a  O4/26/24 0 Initial issue  D.Castillo C. Villanueva A. Arañes n/a					Insertion jig B	Povision History	Locking										
0-4/20/24 0   milital issue   7. Aranes   1/4   7. Aranes   7. Ara	I					TO FIGURE 1 HOLDEY						Prepared by	Rev	newed by	Approved by	Noted by	
				·								Castillo		of form		n/a	
Lit. Date Nev. 140 Reviews 7-ppi oved Reviews 7-ppi					Details of Cl	nange		Revised	Reviewed			Est. Date:	_		A. Al <del>a</del> ries	11/d	

		WORK INSTRUCTION	Effectivity Date:	April 30, 2024			
	Process Name/Title:		Validity Date:	n/a			
	Model code/Part number:	930B / 7N0204-7020Ca Customer: TRJ Car Model: TOYOTA-4 RUNNER	Document No.:	WI-ENG-PDE-879			
	Purpose:	□ PROTOTYPE □ PRE-LAUNCH ■ MASSPRO	Revision No.:	1 Page No.: 2 of 9			
PARTS: 1. Co	onnector 6188-0066 (GR)		JIG:	Insertion jig with switch cover			
NO.	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION	TOOLS/PPE	QUALITY POINTERS			
2 Offlia	Connector setting to	Insertion jig with switch cover  Visual reference  INSERTION JG ORIENTATION  INSERTION JG ORIENTATION  1. Press the lock using left hand.  2. Get the connector 6188-0066 (GR) using right hand and insert to insertion jig. Release the lock after insertion.  3. Push the lower wire guide upward using right hand. Slot for Yellow wire will be opened.	n/a	CONNECTOR ORIENTATION ILLUSTRATION  I-mark is align  2 holes are open not align  NG  1. Use the provided jig per model 2. No wrong orientation of connector 3. No wrong use of connector 4. No damaged connector Important reminders/Note/s: 1. Follow the connector orientation			



				WORK INSTRUCTION		Effectivity Date:	April 30, 2024					
		Process Name/Title:		OFFLINE ASSEMBI	Y PROC	ESS		Validity Date:	Date: n/a			
		Model code/Part number:	930B /	<b>7N0204-7020Ca</b> Customer:	TRJ	Car Model:	TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-8	79	
		Purpose:	PROTOTYPE	☐ PRE-LAUNCH		MASSP	PRO	Revision No.:	1	Page No.:	3 of 9	
PARTS:	1. AVS	Sf Y-OR L=364±2mm		JIG:	Insertion jig with switch cover							
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(	QUALITY POIN	TERS	
3	Offline	Wire Insertion to connector 6188-0066 (GR)	1. Hold the insertice the Yellow wire the using right hand.  3. Get the Orange terminal slot 2 using the using the terminal slot 2 using the termina	wire then insert to ar	2. Press the slot for Or	Press	Ing right thumb. The II be opened.		Importa 1. Please 2. Make s inserted. Conduct insertion Do not e.  Docume 1. Refer Push pro 2. Refer t	and insertion one insertion rmed terminal and wire facing  ant reminders/N e hold the wire ne- sure wires are pro- insert extra force.  ent references: to GL-PRO-ASY-0	ar terminal. operly ush after  29 for Pull- 17 for Wire	


				WORK INSTRUCTION		Effectivity Date:	April 30, 2024			
		Process Name/Title:		OFFLINE ASSEMBLY I	PROCE	ESS	Validity Date:		n/a	
		Model code/Part number:	930B /	<b>7N0204-7020Ca</b> Customer:	ΓRJ	Car Model: TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-8	79
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	4 of 9
PARTS:	1. Assy 2. Black	JIG:	n/a							
NO.	F	ROCESS NAME		WORK PROCEDURE/ ILL	USTRA	TION	TOOLS/PPE	(	QUALITY POIN	TERS
4		Wire insertion to Black corrugated tube ø7 L=45±3mm (No slit)	L		R	1.Get the Black corrugated tube ø7 L=45±3mm (No slit) using right hand and insert Yellow wire and Orange wire by using left hand.	n/a		g use of parts rmed terminal	
5	Offline	Wire insertion to Black corrugated tube ø5 L=266±4mm (No slit)	L	Ø7 L= 45±3mm Ø5 L=	R 266±4m		n/a		ig use of parts rmed terminal	



			WORK INST	Effectivity Date:	April 30, 2024				
		Process Name/Title:	OFFLINE	ASSEMBLY PROC	CESS	Validity Date:		n/a	
		Model code/Part number:	930B / 7N0204-7020Ca	a Customer: TRJ	Car Model: TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-8	79
		Purpose:	☐ PROTOTYPE [	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 9
PARTS:	1. Conr	nector 6189-1161 (B)				JIG:	1. Insertion jig		
NO.	F	PROCESS NAME	WORK PR	TOOLS/PPE	(	QUALITY POIN	TERS		
6	Offline	Connector setting to insertion jig 6189-1161 (B)	INSERTION JIG  Visual  Butto  Guide  Press  1. Press the lock using left thumb.	Press  2. Get the connector 61 insert to insertion jig. Re	CONNECTOR ORIENTATION  Release  89-1161 (B) using right hand and elease the lock after insertion.  re guide upward using right hand.	n/a	I-mark aligned	GOOL is not	ole is open  ole i

WORK INSTRUCTION Effectivity Date: April 30, 2024 Process Name/Title: OFFLINE ASSEMBLY PROCESS Validity Date: n/a											
		Process Name/Title:				CESS	Validity Date:		n/a		
		Model code/Part number:	930B /	<b>7N0204-7020Ca</b> Custom		Car Model: TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-8	379	
		Purpose:	PROTOTYPE			MASSPRO	Revision No.:	1	Page No.:	6 of 9	
PARTS:	1. Assy	parts					JIG:	1. Insertion	jig		
NO.	F	ROCESS NAME		WORK PROCEDU	RE/ ILLUSTR/	ATION	TOOLS/PPE	QUALITY POINTERS			
7	Offline	Connector setting to insertion jig 6189-1161 (B)	Yellow wire then i right hand.		2. Press th slot for Ora  4. After insertior and then hold then hold then hold then hold the hold the hold the hold then hold then hold the hold th	Press R  The button using right thumb. The lange wire will be opened.  Press R  The	n/a	4. No defoi 5. No wron Importa 1. Please 2. Make s inserted. Conduct insertion Do not ex Docume 1. Refer to Push pro 2. Refer to	g insertion one insertion rmed terminal g wire facing  nt reminders/N hold the wire ne sure wires are pr Pull-Push-Pull-Pi cert extra force. ent references: to GL-PRO-ASY-0	ear terminal. roperly  Push after  2029 for Pull- 2017 for Wire	

				WORK INSTRUCTION	Effectivity Date:	April 30, 2024						
		Process Name/Title:		OFFLINE ASSEM	<b>BLY PRC</b>	CESS		Validity Date:		n/a		
		Model code/Part number:	930B /	<b>7N0204-7020Ca</b> Custome	TRJ	Car Model:	TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-8	379	
		Purpose:	PROTOTY	PE PRE-LAUN	ж	MASSE	PRO	Revision No.:	1	Page No.:	7 of 9	
PARTS:	1. Assy	parts		JIG:	1. Locking	jig						
NO.	F	ROCESS NAME		WORK PROCEDUR	≣/ ILLUSTI	RATION		TOOLS/PPE	QUALITY POINTERS			
8	Offline	Connector lock		Connector loc  NG  NG  Half	k appear  G  Lock ition	rance	Condition	LOCKING JIG	1. WANU DAMAG	ck/half-locked con	o lock the	





W	ORK INSTRUCTION		Effectivity Date:		April 30, 2024						
Process Name/Title:	OFFLINE ASSEMBLY PROC	ESS	Validity Date:		n/a						
Model code/Part number: 930B / 7N02	04-7020Ca Customer: TRJ	Car Model: TOYOTA-4 RUNNER	Document No.:	WI-ENG-PDE-879							
Purpose: PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	9 of 9					
PARTS: 1 Assy parts			JIG:	n/a							
	VISUAL INSP	ECTION									
OFFLINE INSERTION 7N0204-7020C											
3 1 2 5	5	1			GO(	OD					
					NO G	OOD					
1 No Wrong insert	No Term Out	ninal Backing	(5) No I	Missi	ng CO	T					
No Unlock/ Half Lock Connector	4 No Defo	rmed terminal	6 Check	the A	Alignm	nent					