	WORK INSTRUCTION Effectivity Date: October 21, 2024										124			
			Process Name/Title:	_	OFFLINE ASSEMBLY PROC	CESS				dity Date:		n/a		
			Model code/Part number:	240B / 7M0514-70		Car Model:	LEX	XUS-ES		ument No.:		WI-ENG-PDE-1	124	
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSI			Rev	ision No.:	1	Page No.:	1 of 8	
PARTS:								JIG:		Insertion jig     Locking jig				
N	0.	F	ROCESS NAME	V	ORK PROCEDURE/ ILLUSTR	ATION				TOOLS/PPE		QUALITY POINTERS		
					Table Lay-out				.    -	Bafety Instructi Be sure to wear required persona protective equipm during operation (gloves, finger cot etc.)	Docun	nent reference/s r to WI-PRO-CNC- o Length Tolerance	017 for Wire	
1		OFFLI NE	Table lay-out	Conn 6188-00						Housekeeping Maintain and alw practice 5's. Personal things the workplace is prohibited. Keep it your locker.	gays on 1. No miss	No missing parts/tools     No excess parts/tools		
		AVSSf 0.3 Black wire L=825±3mm  AVSSf 0.3 Black wire L=825±3mm												
			<u> </u>	Revision	History				<u> </u>	Prepared by	Reviewed by	Approved by	Noted by	
													ŕ	
10/21/24	1	Changa	from Pre-launch to Masspro.			D.Castillo	C.	A. Arañes	n/a	-				
10/21/24	0		•	nnector and connector lock from Taping	assembly process.	D.Castillo  D.Castillo	Villanueva C. Villanueva	A. Arañes  A. Arañes	n/a n/a	Jestus	South ifform	SANTA		
Eff. Date	Rev. No			Details of Change		Revised	Reviewed	Approved	Noted	D. Castillo Est. Date:	C. Villanueva October 17, 2024	/ ACArañes	n/a	




			WORK INS	Effectivity Date:	October 21, 2024						
		Process Name/Title:	OFFLII	NE ASSEMBLY P	ROCESS		Validity Date:	n/a			
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ	Car Model:	LEXUS-ES	Document No.:	WI-ENG-PDE	-1124		
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPRO	)	Revision No.:	1 Page No.:	2 of 8		
PARTS: 1. Connector 6188-0066 (GR)							JIG:	1. Insertion jig			
NO.	F	ROCESS NAME	WORK I	PROCEDURE/ ILLUS	TRATION		TOOLS/PPE	QUALITY POINTERS			
2	OFFLI NE	Connector setting to insertion jig 6188-0066 (GR)	INSERTION JIG ORI  Lock  Press  1. Press the lock of insertion jig using left thumb.	Visual Reference  2. Insert the connector hand then release the Note: Follow the connector hand the connecto	lock.	Release  nto jig using right	n/a	GOOD	holes are open  holes are open  holes are open		

WORK INSTRUCTION Effectivity Date: October 21, 2024											
		Process Name/Title:		NE ASSEMBLY	PROCESS		Validity Date:	-	n/a		
		Model code/Part number:	240B / 7M0514-7021B	Customer: TF		LEXUS-ES	Document No.:	WI-ENG-PDE-1124			
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO		Revision No.:	1	Page No.:	3 of 8	
PARTS:	1. AVSS	Sf 0.3 Black wire L=825±3mm	[2pcs]	]					JIG: 1. Insertion jig		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILL	USTRATION		TOOLS/PPE	QUALITY POINTERS			
3	OFFLI NE	Wire insertion to Connector 6188-0066 (GR)	1. Get the first Black wire then insert 1 using right hand. (Note: Insertion of wires must be from	to terminal slot In left to right.)  3. After inser thumb and the		g left gently pull	n/a	2. No wrong 3. No dama 4. No wrong 5. No loose 6. No wrong 7. One by o 8. No defor 9. No wrong 1. Please 2. Insertito right. 3. Make a inserted. after inserted. Do not e  Docume 1. Refer inserted. 2. Refer o 2. Refer o	g insertion one insertion med terminal g wire facing  at reminders/Note e hold the wire ne ion of wires must sure wires are pr . Conduct Pull-Pu ertion. xert extra force.  ent references: to GL-PRO-ASY-0	v/s: ar terminal. be form left roperly rsh-Pull-Push : 229 for Pull-	

			WORK INS	Effectivity Date:	October 21, 2024					
		Process Name/Title:		NE ASSEMBLY I	PROCESS		Validity Date:		n/a	
		Model code/Part number:	240B / 7M0514-7021B	Customer: TR	Car Model:	LEXUS-ES	Document No.:	WI-F	ENG-PDE-1124	
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO		Revision No.:	1 Pag	ge No.: 4	of 8
PARTS:			Work	PROCEDURE/ ILLU			JIG:	1. Insertion jig		
NO.	F	PROCESS NAME	TOOLS/PPE	QUALI	TY POINTERS					
4	OFFLI NE	Connector setting to insertion jig 6188-0066 (GR) (assy parts)	INSERTION JIG ORII  Lock  Push  R  2. Insert the connector 6188-0066 (GR into jig using right hand then release th Note: Follow the connector orientation.	Visual Reference  Reference  Release  With assy parts le lock.	CONNECTOR O  1. Push the insertion jig  3. Check the holes G wire is open.	e guide lock of using right thumb.	n/a	I-mark is align	GOOD 2 hole is	open

WORK INSTRUCTION Effectivity Date: October 21, 2024											
		Process Name/Title:		INE ASSEMBLY PRO	OCESS		Validity Date:	n/a			
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ	Car Model:	LEXUS-ES	Document No.:		WI-ENG-PDE-11	124	
		Purpose:	PROTOTYPE	□ PRE-LAUNCH	■ MASSPRO		Revision No.:	1	Page No.:	5 of 8	
PARTS:	1. Assy	parts					JIG:	1. Locking jig			
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUST	RATION		TOOLS/PPE QUALITY POINTER			ΓERS	
5	OFFLI NE	Wire insertion to Connector 6188-0066 (GR) (Assy parts)	1. Get the MR SW CP wires then ho the G wire to terminal slot 1 using rig After insertion, press the button usin thumb and slot for B/W will be opened.	ght hand.  ng right ed.  2. Get the Minsert to term	AR SW CP Black/minal slot 2 using  3. After insertion, using left thumb a wires and gently pronnector from jig	push the lock nd then hold the bull out the	n/a	2. No wrong 3. No dama 4. No wrong 5. No loose 6. No wrong 7. One by o 8. No defor 9. No wrong 1. Please 2. Insertito right. 3. Make a inserted. after inserted. after inserted. Do not e  Docume 1. Refer in Septical Push pro 2. Refer o 2. Refer o 3. Refer o 3. Make o 4. Refer o 4. Refer o 4. Refer o 5. Refer o 6. Refer	g insertion one insertion med terminal g wire facing  nt reminders/Note e hold the wire ne eion of wires must sure wires are pr . Conduct Pull-Pu ertion. xert extra force.  ent references: to GL-PRO-ASY-0	/s: ar terminal. be form left operly sh-Pull-Push : 129 for Pull-	

			WORK IN	Effectivity Date:	October 21, 2024					
		Process Name/Title:	OFFL	INE ASSEMBLY PRO	CESS		Validity Date:		n/a	
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ	Car Model:	LEXUS-ES	Document No.:		WI-ENG-PDE-1	124
		Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPRO	)	Revision No.:	1	Page No.:	6 of 8
PARTS:	1. Assy						JIG:	1. Locking j		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	QUALITY POINTERS		
6	OFFLI NE	Connector lock	Before pressing  After pressing	R  Connector Cros  NG  Unlock  Ha	en conduct 2x properly locked.	al View GOOD Full Lock Condition	LOCKING JIG	1. Manudamage	ment references ual locking may co ed connector lock provided locking jig p k/half-locked connect aged lock	ause



			Effectivity Date:		October 21, 2024					
		Process Name/Title:	OFFLINE	OFFLINE ASSEMBLY PROCESS					n/a	
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ	Car Model:	LEXUS-ES	Document No.:		WI-ENG-PDE-1	124
		Purpose:	☐ PROTOTYPE ☐	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	8 of 8
PARTS:	1. Assy	parts					JIG:	n/a		

**VISUAL INSPECTION/ QUALITY CHECKPOINTS** 

## **OFFLINE INSERTION**

## 7M0514-7021B



- 1 No Unlocked/Half-locked connector
- **2 No Wrong Insert**
- **3 No Terminal Backing Out**
- **4** No Deformed Terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.