

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-518

May 5, 2022

WORK INSTRUCTION Product Code/Name:

Customer Code: NBS

Effective Date: Rev. No.:

			Product Code/Name 7H0309W7020D		Customer Code: NBS	Rev. No.:		0		Page No.:	Page	e 1 of 1
No.	Work Procedure/ Illustration									Records/Remarks/ Quality Pointers		
							ON EVER	a a		Qty/ Box	60 pcs	10pcs* 6bdls
	Put Vinyl Sheet (1520 x 1500) inside the box.								Mat'l name Master	535*360*	Qty 1	
1									box Vinyl	150 mm 1520*1500	1	
										Sheet Plastic		
								1		Vinyl Bag	300*200mm	6
2	Put th		t 3 bdls of products. 10pcs/bdl)							Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 5 is applicable only in QC FG Inspection. One bundle has NBS		
	Put the 2nd 3 bdls of products (10pcs/bdl) in opposite direction					The Carlot	ATE .				er tag inside th nyl bag	e
3										SA	AMPLE INNER T	¥ C
									Make sure that the inner tag indicates the			
4	Fold the vinyl sheet.									ad the filler tag		
(5)	Clip NBP Identification tag and NBS Tag at the left side of the box											
6	left s	ide o	dentification tag at the f the box and NBP g in the right side of the box.	7H0309W7020D ure 04-22 w 13 60					Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.			
ļ	<u> </u>	 					ļ			Prepare	Check	Approve
05/05/2022	0			ا المثقام!	NO. III					(Jan)		
05/05/2022 Eff./Rev. Date	Rev. No.			Initial Is Details of			J. Loterte Revise	C. Villanueva Check	A. Arañes Approve	J. Loterte Est. date	C. Villanueva May 5	A. Arzīñes , 2022
							•					

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) MASTER COPY