				WORK II	NSTRUCTION				Effecti	ivity Date:		April 12, 2025	i	
NE									Validit	Validity Date:		n/a		
			Model code/Part number:	310D / 7N0246-7020	Customer: TRJ	TRJ Car Model:		OTA-RAV4	Document No.:			WI-ENG-PDE-1231		
		4	Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPI	RO		Revisi	on No.:	1	Page No.:	1 of 4	
PARTS:			SV tube (Vinyl) ø5 L=130±3							JIG:	n/a			
NO	Э.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION							TOOLS/PPE	1	QUALITY POINTERS			
		P1	Table Lay out	TABLE LAY OUT Black SV tube (Vinyl) ø5 L=130±3mm					pro	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Document reference/ 1. Refer to WI-PRO-CNC-C Strip Length Tolerance				
1				Assy Parts			Tape holder / Blue tape	1. M 2. F tl			No missing parts/tools No excess parts/tools			
				23456789(2)123456	7 8 9 6 7 1 2 3 4 5 6 7 8 9	CD 1 2 3 4 5	,6789	KD 1 2 3 4 5 6	the s S Lea	Alert level any trouble, information Assembly Assistate and the control of the control of the control and the control of the control	ant			
				Revision History					1	Prepared by	Checked by	Reviewed by	Approved by	
04/12/25 03/29/25		Change p	re-launch to masspro le			A. Buban A. Buban	J. Loterte J. Loterte		. Arañes	Herrandra.	J.Loverte	C. Villanueva	A. Assaries	
Eff. Date	Rev. No			Details of Change		Revised	Checked	Reviewed Ap	oproved I	Est. Date:	March 29, 2025			
					_									

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COI

MASTER COPY

			WORK INS	Effectivity Date:	April 12, 2025						
		Process Name/Title:	TAPIN	Validity Date:	n/a						
		Model code/Part number:	310D / 7N0246-7020	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:	WI-ENG-PDE-1231			
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPR	0	Revision No.:	1	Page No.:	2 of 4	
PARTS:	1. Assy parts 3. Black SV tube (Vinyl) ø5 L=130±3mm 2.Blue tape [1pc]					JIG:	n/a				
NO.	F	PROCESS NAME	WORK F	PROCEDURE/ ILLUST	RATION		TOOLS/PPE	QUALITY POINTERS			
3		Wire Insertion to Black SV tube (Vinyl) ø5 L=130±3mm		R	1. Get the Bla (Vinyl) ø5 L=1 right hand the wires.	ck SV tube 30±3mm using n insert the B-B	n/a		g usage of parts med terminal		
4	P1	Taping 1 SV tube (Vinyl) to wire near Connector	1. Get the Blue tape using right hand then start taping process usin both hands. 25±3mm 25±3mm 25±3mm 3. After taping, check the measureme	25±3mm 2. Hold the Coend of COT u 0-5mm L 9 21	OT using left har p to connector 2:	d and measure from 5±3mm.		1. No flip-c 2. No peel 3. No loose 4. No miss 5. No wron 6. No wron 1. Please measurin measurer Docume	out tape -off tape e tape ing tape g dimension g use of tape nt reminders/n use calibrated/ve g tape when get	ote/s: erified ting the	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

		D 1 (T)	Effectivity Date:	April 12, 2025								
		Process Name/Title: Model code/Part number:	TAPING ASSEMBLY PROCESS 310D / 7N0246-7020 Customer: TRJ Car Model: TOYOTA-RAV4				Validity Date: Document No.:	n/a WI-ENG-PDE-1231				
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	ικυ	MASSPR		Revision No.:	1	Page No.:	3 of 4	
		i dipose.	_ TROTOTTE	TRE-EAUNOIT		■ WASSPR		TOVISION NO.	<u> </u>	i age ivo	3 01 4	
PARTS:	1.Assy l								n/a			
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POIN	TERS		
			←	③ 229 ±4 ⑥ 0 +10					1. No wrong usage of parts 2. No deformed terminal Wire alignment tolerance		lerance	
3	P1	Measurement	① 40 ± 4 ① 0 +2 ① NOTE:	Vinyl Tube	e (B) Ø5	4) 20 +2	A -		1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape			
			Taping (L) *UNIT OF DIMENSION: millimeter (mm) *MEASURING TOOL: measuring tape				No. 1 2	WIRE TYPE TABLE Color Wire Type B AVSS 0.3 f B AVSS 0.3 f MEASURING TAPE	Importa 1.Please measurin measurei	nt reminders/n use calibrated/v g tape when get	erified ting the	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.


NBC (Philippines)
MASTER COPY

			WORK INSTRUCTION					Effectivity Date: April 12, 2025		
		Process Name/Title:	TAPI	NG ASSEMBLY I	PROCESS		Validity Date: n/a		n/a	
		Model code/Part number:	310D / 7N0246-7020	Customer: TR	Car Model:	TOYOTA-RAV4	Document No.:	WI-ENG-PDE-1231		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPR	0	Revision No.:	1	Page No.:	4 of 4
PARTS: 1.Ass		Parts			JIG:	n/a				

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING P-1

7N0246-7020



No Missing and No Wrong used of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY