

	Process Name/ Title:	Document No:		WI-QAD-QAC-235			
	PACKING INSTRUCT						
ı	WORK INSTRUCTION			Date:	July 5, 2024		
	Product Code/Name:	Customer Code:					
	71 0120	TROSS	Rev. No.:	1	Page No.:	Page 1 of 1	

			7L0120	TRQSS	Rev. No.: 1	Page No.	: Page '	1 of 1		
No.		Work Procedure/ Illustration						Records/Remarks/ Quality Pointers		
1		Put Vinyl (1250 x 1250)				Qty/box Mat'l name	120 Dim.	60pcs *2bdls Qty.		
	insi	de carton box.				DC carton	1131*781	1		
					$\frac{\sqrt{1}}{2}$	Vinyl sheet	1250*1250	1		
						Vinyl bag	420*280	2		
2	Put second bundle on the other side with opposite direction					Note: 1 Step 5 is a inspection	∶FG			
3										
4	Fold the vinyl sheet									
(5)	tag (Inn	ne flaps and put ID er tag at the top of tic and Outer tag at side of the front of the box).			to attach 4M tag tag at the left side					
					Prepare	Chec	cke Ap	oprove		
07/05/2024	1	Change Vinyl Sheet Size from	o. from WI-ENG-PDE-247 to WI-QAD-QAC n 1520x1500 to 1250x1250; Change picture I and Addition of no. 5; Modify note.	J. De La Cruz D.Dadulla	R.Pascua		ig/	14		
02/25/2021 Eff./Rev. Date	0 Rev. no.		Initial issue. Details of change	J. Loterte C. Villanueva Prepared Checked	A. Shimamura Approved Established.	ruz D.Dao	february 25, 2021	∦asobla 1		
LII./INEV. Dale	1 1.64.110.	<u> </u>		i ispaicu Cilecked	Approved Established.	adio.	1 651uary 20, 202			

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

