				WORK IN	Effectivity Date:	fectivity Date: October 22, 2024							
			Process Name/Title: CLAMP ASSEMBLY PROCESS							n/a			
			Model code/Part number:	890B / 7L0098-7020	Customer: <b>T</b>	RQSS Car Model:	TOYOTA- C-SUV	Document No.:		WI-ENG-PDE-9	35		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	0	Page No.:	1 of 7		
PARTS: 1. Assy parts: Clamp 82711-52090 (W); Clamp 82711-34490 (B); Clamp 82711-35730 (B); Black tape [3pt NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATED NO. PROCESS NAME								JIG:		Clamp Assembly jig     QUALITY POINTERS			
N	0.	Р	ROCESS NAME	WORK	PROCEDURE/ ILI	LUSTRATION		TOOLS/PPE		QUALITY POIN	TERS		
1		Clamp		Clamp 82711- 34490 (B)/ Clamp box	Clamp 82711-52090 (W)/ Clamp tray	Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)	1. Refer t	Document reference/s:  1. Refer to WI-ENG-PDE-126 for Taping assemmbly process					
	1		Table Lay-out	Clamp 82711-35730 Clamp tray	(B)			Housekeeping  1. Maintain and always practice 5's.  2. Personal things on the workplace is prohibited. Keep it in your locker.	No missing parts/tools     No excess parts/tools				
							Clamp assembly jig	Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.					
					pe holder/ ack tape			BANDO					
	Revision History Prepared by Reviewed by Approved by									Approved by	Noted by		
							Villanuov	Jatulo Catulo	1/h-ita-				
10/22/24		Initial issu	ue. Separate Clamp assy to Cla	amp assembly process.		D.Castillo	C.Villanuev A. Arañes	n/a D. Castillo	C. Villanueva	A. Aranes	n/a		
Eff. Date	Rev. No			Details of Change		Revised	Reviewed Approved N	oted Est. Date: Octo	ober 22, 2024				


**MASTER COPY** 

			WORK INS	TRUCTION			Effectivity Date:		October 22, 202	4	
		Process Name/Title:	CLAM		Validity Date:	n/a					
		Model code/Part number:	890B / 7L0098-7020	Customer:	TRQSS Car Mod	E TOYOTA- C-SUV	Document No.:		WI-ENG-PDE-93	5	
		Purpose:	PROTOTYPE	PRE-LAUNC	H MA	SPRO	Revision No.:	0	Page No.:	2 of 7	
PARTS:	1.Clamp 82711-34490 (B) 2. Clamp 82711-52090 (W)			JIG:	1. Clamp Assembly jig						
NO.	F	PROCESS NAME	WORK F	ROCEDURE	/ ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS			
2	Clamp	Clamp Setting	1. Get 1 pc. of band clamp 82711-344 set to clamp location 1 using both han  2. Get 1 pc. of clamp 82711-35730 (B clamp location 2 using both hands.	82711-35 3 90 (B) then ds.	3. Get 1 pc. of clamp to clamp location 4 using	2711-52090 (W) then set ng both hands.	n/a	I. No dam 2. No wrot 3. No wrot 4. No miss  STAN  CO  Importa 1. Please start of as clamp.  Bu  GOOD	aged clamp ng use of clamp ng use of tape sing clamp  IDARD TAPING FO  One wind for under  One wind for under  Check the Clamp file Seembly to avoid wind  AND CLAMP ILLUST  CLAMP ILLUSTRATION  NG	or CLAMP  er tape  orte/s: st before ong use of	

			WORK INS	Effectivity Date:	October 22, 2024									
		Process Name/Title: CLAMP ASSEMBLY PROCESS Validity Date:							n/a					
		Model code/Part number:	890B / 7L0098-7020	Customer: TRQSS	Car Model: TC	OYOTA- C-SUV	Document No.:		WI-ENG-PDE-93	35				
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	3 of 7				
PARTS:	1. Assy	parts					JIG:	1. Clamp A	Assembly jig					
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR/	ATION		TOOLS/PPE	QUALITY POINTERS						
3	Clamp	Clamp Assembly	Receiver base 1  1. Get the assy parts and set into jig. (See to set the harness then last, set the B-B w 1 was on.  2. Check if all LED light for POWER ON, the attention of the leader. WAIT for furthe 3. Initially tighten the band clamp on local hands.	82711-35730 (  SW Button  SW Button  SW Button  SW Button  SW Button  Above picture for correct setting). Wires together within the stopper the rinstruction and continue the procure instruction an	First, set the connected press by Toggle was ON. If encount cess.	tered abnormality, STOP  using right hand then cube process if sequence li	and immediately CALL	2. No wror 3. No miss 4. No miss 5. No loos  Importo 1. Make jig and t 2. Using cut mea dimensi allowabl (0~2mm)	ant reminders/N sure no gap betweerminals. steel rule, check surement is within on and should not e range ).  BANDO GUN ILLUSTRAT	Note/s: een stopper if the band in the required it exceed the				

			WORK INS	STRUCTION		Effectivity Date:		October 22, 202	24
		Process Name/Title:		IP ASSEMBLY PRO	OCESS	Validity Date:	+	n/a	
		Model code/Part number:	890B / 7L0098-7020		SS Car Model: TOYOTA- C-SUV	Document No.:		WI-ENG-PDE-9	35
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 7
PARTS:	1. Assy parts					JIG:	1. Clamp /	Assembly jig	
NO.	F	PROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS				
3	Clamp Assy	Clamp Assembly (Continuation)	Receiver base 1	3 3 3	5. Conduct spot taping on COT in cludings only then cut the tape .Press Note: No exessive windings of tag  6. Press the clamp (82)	the SW button after taping.	1.Make stopped 2. Make taping.	naged clamp ng usage of parts sing clamp	etween als.

				STRUCTION			Effectivity Date:		October 22, 202	24		
		Process Name/Title:	CLAN	IP ASSEMBLY	PROCESS		Validity Date:	n/a				
		Model code/Part number:	890B / 7L0098-7020	Customer: T	TRQSS Car N	lodel: TOYOTA- C-SUV	Document No.:	WI-ENG-PDE-935				
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	Revision No.:	0	Page No.:	5 of 7		
PARTS:	1. Assy parts						JIG:		Assembly jig			
NO.	F	PROCESS NAME	WORK	PROCEDURE/ IL	LUSTRATIO	1	TOOLS/PPE	(	QUALITY POINTERS			
3	Clamp Assy	Clamp Assembly (Continuation)	Receiver base 1  8. Tape the clamp on location 4 using by then cut the tape. Press the SW button will be heard.	82711	1-35730 (B) SW Button  ands 9. Condu	hands. Make 3 win Press the SW butto	ys of tape.	1. No wron 2. No wron 3. No Loos 4. No loose 5. No peel 6. No dam	-off tape aged clamp ng use of tape	ween clamp mp		





		WORK INSTRUCTION						Effectivity Date:	October 22, 2024		
		Process Name/Title:	ess Name/Title: CLAMP ASSEMBLY PROCESS						n/a		
		Model code/Part number:	890B / 7L0098-7020	Customer:	TRQSS	Car Model:	TOYOTA- C-SUV	Document No.:		WI-ENG-PDE-9	35
		Purpose:	PROTOTYPE	PRE-LAUNCH	I	MASSP	RO	Revision No.:	0	Page No.:	7 of 7
PARTS:	1. Assy	/ parts						JIG:	n/a		

## **VISUAL INSPECTION/ QUALITY CHECKPOINTS**

## **CLAMP ASSY**

## 7L0098-7020



- No Wrong Facing of Clamp (2) No Unlock/Halflock connector (3)(4) No Missing Tape (Black Tape )



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.