

			WORK IN:	STRUCTION			Effectivity Date:		October 15, 20)24		
		Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:		n/a			
		Model code/Part number:	780 / 7R0105-7023B Customer: TRMX Car Model: TOYOTA-TUNI				Document No.:		WI-ENG-PDE-1088B			
		Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPRO		Revision No.:	1	Page No.:	1 of 8		
PARTS:	1. All pa	rts: Clamp 82711-52090 (W);	Clamp 82711-16830 (B); Clip type clamp 8:			JIG:	1 1 7 1 1 7 7 7 7					
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTR						TOOLS/PPE	(QUALITY POIN	ITERS		
1	Clamp 82711-52090 (W)/Clamp Tray Clamp 82711-16830 (B)/Clamp Tray Clip type clamp 82711-1E360 (W)/Clamp Tray Assy parts Bando gun					Label dispenser Clamp assembly jig	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action. Prepared by Reviewed by Approved by Noted by Prepared by Reviewed by Approved by Noted by Noted by Prepared by Reviewed by Approved by Noted by Not					
			Revision History				Prepared by	Reviewed by	Approved by	Noted by		
10/15/24 1	Change f	rom Pre-launch to Masspro.			A. Hernandez C.	Villanueva A. Arañes	n/a O.0 o	1/-12-11	A AM			
10/14/24 0	Initial Iss	•					n/a Okum On div A. Hernandez	C. Villanueva	A. Arañes	n/a		
Eff. Date Rev. N	0		Details of Change		Revised R	eviewed Approved N		October 14, 2024		_		








			WORK IN	Effectivity Date:	October 15, 2024				
	AL	Process Name/Title:	Validity Date:	n/a					
		Model code/Part number:	TAPIN 780 / 7R0105-7023B	Document No.:	WI-ENG-PDE-1088B				
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 8
PARTS:	1. Assy parts					JIG:	1. Clamp assembly jig		
NO.	F	ROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS				
4	P2	Connector lock	1. Put the connector into locking jig us hand then press 2x to lock using both Check the lock if properly locked.	Double Double		Locking Jig	2. N Important 1. MANUA	the provided locking o unlock/half-locked t reminders/Note L LOCKING MAY (O CONNECTOR.	I connector












				WORK INSTRUCTION					October 15, 2024		
			Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:	n/a		
			Model code/Part number:	780 / 7R0105-7023B	Customer:	TRMX	Car Model: TOYOTA-TUNDRA	Document No.:		WI-ENG-PDE-10)88B
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	l	■ MASSPRO	Revision No.:	1	Page No.:	8 of 8
-]											
	PARTS:	1. Assy	. Assy parts					JIG:	n/a		
ıſ	VISUAL INSPECTION/ QUALITY CHECKPOINTS										

TAPING - P2

7R0105-7023B



- 1 No Missing / Mis-align of Clamp
 2 No Unlocked/Halflocked Connector
 - 3 No Missing QR code label

4 No Missing Tape (Black Tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.