
NB			WORK INSTRUCTION					Effectivity Date:		July 12, 2024	
		Process Name/Title:	174 110 7100 2111 22 1 1 1 1 1 1 1 1 1 1 1 1 1 1						Validity Date: n _i		
		Model code/Part numbe	D10L / 7M0654-7020A	Customer: TI	RJ Car Model	DAIHATSU-1	ANTO	Document No.:		WI-ENG-PDE-1	56C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO		Revision No.:	4	Page No.:	1 of 4
PARTS:		Assy parts ;Black tape					JIG:	n/a			
NO.		PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE		QUALITY POINTERS		
1		P3 Table Lay-out	Assy parts	UT			Safety Instruction Be sure to wear prescribed persons protective equipme during operation (gloves, finger cots etc.) Housekeeping 1. Maintain and alwa practice 5's. 2. Personal things of the workplace is prohibited. Keep it your locker.	al al nt s, s, s s s s s s s s s s s s s s s s	1. No mising parts/tools 2. No excess parts/tols		
			Revision History DE-156B) due to process improvement. Inclusion of car model "DAIHATSU-TANTO" D. Castilla C. A Ansia				Alert level For any trouble, info the Assembly Assist Supervisor or Line Leader for immedia corrective action. Prepared by	ant e	eviewed by Approved by Noted by		
07/12/24	4	and Table lay-out. Improved Measurement and Visual inspection/Quality checkpoints. D.Casillio Villanueva A. Aranes A. Aranes					amu	/a			
04/27/21		Change clamp color in accordance with color standardization for plastic parts GL-COM-003; put assy parts on pg.3 J.Loterte Villanueva ra						rañes Jatulo	South Tillow	AND O	
10/09/20		Remove cycle time. D.Castillo Villanueva A. Aranes						D. Castillo C. Villanueva A. Aranes			n/a
Eff. Date	Rev. No		Details of Change		Revised	Reviewed Appro	ved No	ted / Est. Date:	March 1, 2019		




			Effectivity Date:	Effectivity Date: July 12, 2024					
		WORK INSTRUCTION Process Name/Title: TAPING ASSEMBLY PROCESS				Validity Date:	n/a		
		Model code/Part number: D10L / 7M0654-7020A Customer: TRJ Car Model: DAIHATSU-TANTO				WI-ENG-PDE-156C			
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	4	Page No.:	2 of 4
PARTS:	Black tape Assy parts					JIG:	n/a		
NO.	PROCESS NAME		WORK F	TOOLS/PPE	QUALITY POINTERS				
2	P3	Y-taping 2	With Wide interval 1. Fix the SV tube. 2. Measure from SV tube (Vinyl) up to SV tube (Vinyl) 20mm. Tape the SV tube (Vinyl) 1/3 shifting going to wire then cut the tape. 1. Fix the SV tube. 2. Measure from SV tube (Vinyl) ap to SV tube (Vinyl) 1/3 shifting going to wire then cut the tape.		MEASURING TAPE 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1. Use visualizactual sacrual sacrual sacruals measur measur 1. No loos 2. No flip-c 3. No peel	e tape out tape	eady ing nut TAPE verified ting the	









NBC (Philippines)
MASTER COPY