

## **PACKING INSTRUCTION**

Process Name/ Title:

Document No:

WI-QAD-QAC-228

WORK INSTRUCTION

Effective Date:

July 5, 2024

Records/Remarks/ **Quality Pointers** 100

Dim.

1131\*781

1250\*1250

420\*280

Step number 5 is applicable only in QC FG Inspection.

Page No.:

Qty/box

Mat'l name

DC carton

Vinyl sheet

Vinyl bag

Note:

Page 1 of 1

50pcs \*2bdls

Qty.

1

1

2

	BU	Pi	roduct Code/Name: 7L0089	Customer Code: TRQSS	Rev. No.:	1	
No.			Work Procedure/	'Illustration			
1	Put Vinyl Sheet (1250 x 1250) inside carton box.						
2	Put first bdl of products. (50pcs/bdl)						
3	Put second bdl on the other side with opposite direction (50pcs/bdl)						
4	Fold the viny	yl sheet.					

ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the (5) box).





Note: If need to attach 4M tag Put 4M tag at the left side

						Prepare	Check	Approve
						,		,
07/05/2024	1	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua	-	Chia	MA
09/19/2023	0	Initial issue	M. Garcia	D. Dadulla	R.Pascua	J. De Jakeruz	D. Dadulla	R.Pascua
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date: September 19, 2023		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. **NBC (Philippines) MASTER COPY**