
				WORK INST			Effectivity Date:		August 12, 202	1
		Process Name/Title:		TAPING	ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Product Name/Code:	970A	/ 17J711-7051P	Customer:	NBC	Document No.:		WI-ENG-PDE-29	9F
		Purpose:	PROT	ОТУРЕ	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 4
	1						1	1		
PARTS:	1. Assy 2. Black	parts TESA Tape No 51036					JIG:	1. Taping ji	g	
NO.	PF	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			RATION	TOOLS/PPE	QUALITY POINTERS		
1	P6	Taping 3 Wire taping (Tesa)	BEFOR		AFTER PRESSING Light Gray Sunprene Tu Black Sunprene Tube the harness on Jig 2. (See pic	R CONNECTOR SETTING	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.		g setting of harness g orientation of conn	ector
<u> </u>	1			Revision History			Prepared by Re	eviewed by	Approved by	Noted by
08/12/21 0 Eff. Date Rev. No	Initial iss	ue	Deta	ails of Change		,		Villanueva t 12, 2021	A. Shimamura	A. Aralives




			WORK INSTRUC	CTION		Effectivity Date:		August	12, 2021
Process Name/Title:			TAPING ASS	SEMBLY PRO	CESS	Validity Date:		n/	/a
Product Name/Code:	970A	1	17J711-7051P	Customer:	NBC	Document No.:		WI-ENG-F	PDE-299F
Purpose:	P	ROTOTY	PE	PRE-LAUNCH	☐ MASSPRO	Revision No.:	0	Page No.:	2 of 4





			WORK INSTRU	CTION		Effectivity Date:		August	12, 2021
Process Name/Title:			TAPING ASS	SEMBLY PRO	CESS	Validity Date:		n/	/a
Product Name/Code:	970A	1	17J711-7051P	Customer:	NBC	Document No.:		WI-ENG-F	PDE-299F
Purpose:	P	ROTOTY	PE	PRE-LAUNCH	☐ MASSPRO	Revision No.:	0	Page No.:	3 of 4



NBC

			WORK INSTRU	CTION		Effectivity Date:		August	12, 2021
Process Name/Title:			TAPING AS	SEMBLY PRO	CESS	Validity Date:		n/	'a
Product Name/Code:	970A	1	17J711-7051P	Customer:	NBC	Document No.:		WI-ENG-F	PDE-299F
Purpose:	P	ROTOTY	PE	PRE-LAUNCH	☐ MASSPRO	Revision No.:	0	Page No.:	4 of 4

n/a		JIG	n/a
NO. PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION	TOOLS/PPE	QUALITY POINTERS
Taping 3 1 P6 Wire taping (Tesa (Continuation)	8. After taping, check the alignment and condition of tape. 9. Proceed to Continuity checking, refer to WI-ENG-PDE-308 if encountered problem, refer to Treatment on Levercon continuity checker NG WI-ENG-PDE-001. 10. Refer to WI-ENG-PDE-309 End Tape Pressing. 11. Refer to IS-ENG-PDE-002 17J711-7051P Inspection Guide.	n/a	1. No loose tape 2. No excessive tape winding 3. No damage on parts 4. No peel off tape 5. No bend Wire Note: Refer to Work instruction of Continuity checking, End Tape Pressing and Inspection Guide fo