


				WORK IN	Effectivity Date:	October 12, 2024				
			Process Name/Title:	TAPII	NG ASSEMBLY PROC	Validity Date:	n/a			
			Model code/Part number:	780B / 7R0106-7022B	Customer: TRMX	Car Model: TOYOTA TUNDRA	Document No.:	WI-ENG-PDE-1104		
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 1 of 6		
PARTS:		1.Assy part; Clip type clamp L=203±3mm (no slit); Black		82711-60270 (L); Black Sunprene tube Ø5 L=125±3mm; Black Corrugated tube Ø5 Tape; White Tape			JIG:	Measuring jig Terminal cover jig		
N	Ο.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS		
NO.		P1	Table lay-out	Black Sunprene tube Ø5 L=125±3mm	Table Lay-out Clip type clamp 82711-60270 (L)/ Clamp tray Black Sunprene tube Ø5		Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the work place is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for	Important reminders/Note/s: 1.Refer to WI-PRO-CNC-017 for wire and Strip Length Tolerance 1.No missing parts/tools 2.No excess parts/tools		
				Measuring jig jig			immediate corrective action.			
Revision History Prepared by Reviewed by Approved by Noted by										
10/12/24	1	1 Change pre-launch to mass pro. A Hernandez C Villanueva A Arañes n/a 00 . // built								
10/12/24		Initial issu	ue.	change pro launon to mass pro.			n/a Okumondu Z.	Villanueva A. Aranes n/a		
	Eff. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: October 11, 2024									







			Effectivity Date: October 12, 2024			24			
		Process Name/Title:	TAPIN	Validity Date:		n/a			
		Model code/Part number:	780B / 7R0106-7022B	Customer: TRMX	Car Model: TOYOTA TUNDRA	Document No.:		WI-ENG-PDE-1	104
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 6
PARTS:	1. Assy	parts				JIG:	n/a		
NO.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POIN	TERS
7	PROCESS NAME P1 Measurement		③ 184±3 ② 39±3 ⑤ 20±3	(6) 20 ±3 (7) 20±3 (8)	COT Ø5 (B), no slit		Please measuring measurer For Ha Owarimon Docume Refer to assembly Owarimon	tsumono, Nakamo	rified g the no and : 66 for Sub-

	Effectivity Date: October 12, 2024										
	Process Name/Title:	Process Name/Title: TAPING ASSEMBLY PROCESS					n/a				
	Model code/Part number:	780B / 7R0106-7022B	B / 7R0106-7022B Customer: TRMX Car Model: TOYOTA TUNDRA			WI-ENG-PDE-1104					
	Purpose:	☐ PROTOTYPE [PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 6			
PARTS: n/a					JIG:	n/a					
	VISUAL INSPECTION/ QUALITY CHECKPOINTS										
TA	TAPING - P1 7R0106-7022B										
				(2)							
				DESCRIPTION OF THE PARTY OF THE		3					
	- THE STATE OF THE	and the state of t	A SA PASSION	THE RESERVE		3					
	accounter		Walley Co.		0			Section 1			
	5							Brown .			
						Carried I	47				
	An inches						15	3 1			
						_	,				
		(2) No Mis	No Missing tape/								
$\ (1)\mathbf{N}\mathbf{C}\ $	Missing	$\langle - \rangle$									
		wrong	use of ta	ipe '	Wrong us	e or	таре				
l CII	p Clamp	/ DI AC	V Topo		/ \A/LITE T	000	1				
		(BLACK Tape)			(WHITE Tape)						