







			WORK INS	Effectivity Date: March 12, 2025			5			
		Process Name/Title: TAPING ASSEMBLY PROCESS				Validity Date:	n/a			
		Model code/Part number:	560B / 17L544-7050	Customer: TRF	Car Model: TOYOTA-INNOVA	Document No.:		WI-ENG-PDE-26	8C	
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	8	Page No.:	4 of 5	
PARTS:	1. Assy	parts				JIG:	1. Insertion	1. Insertion jig		
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
		MEDIUM Wire insertion to Blue VM Tube (Sunprene) ø7 L=55±5mm (Continuation)	BEFORE PRESSING 4. Press the unlock Blue Red Gray Pink Wh Green Orange Black Violet Vello 2 3 0 5	ite Brown Light Green 5. Ho genti	AFTER PRESSING Old the wires using right hand then by pull out the connector from jig. ok the insertion condition.	Finger COTS	2. No rematube 3. No cut to	NDARD TUBE APP	PEARANCE VIG	

		WORK INSTRUCTION				Effectivity Date:	March 12, 2025		
		Process Name/Title: TAPING ASSEMBLY PROCESS				Validity Date:	n/a		
	5	Model code/Part number:	560B / 17L544-7050	Customer: TRP	Car Model: TOYOTA-INNOVA	Document No.:	WI-ENG-PDE-268C		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	8	Page No.:	5 of 5
PARTS:	1. Assy	parts	JIG:	1. WIP Holder					
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS		
4	P3	Pass WIP to P4	3 PIECES FLO	1.1	Pass WIP to WIP Holder. te: Three pieces flow.	WIP HOLDER	1. No WIP overflow		