					WORK INSTRUCTION		Effectivity Date: April 26, 2024			
			Process Name/Title:		TAPING ASSEMBLY PROC	Validity Date:	n/a			
			Model code/Part number:		7N0205-7020Ca Customer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-8	77D
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	1 of 5
PARTS:		1. Assy 2. Blac	k tape					n/a		
NC	Ο.	F	PROCESS NAME		WORK PROCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	(QUALITY POIN	TERS
1		P4	TABLE-LAY-OUT		Assy parts Black with he	tape	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	2. No exce	ing parts/tools ss parts/tools g position of parts	/tools
					Revision History		Prepared by Re	eviewed by	Approved by	Noted by
04/26/24	1 0	Change p	ourpose from Pre-launch to Masspue	ro.		M. Ariola C.Villanueva A. Arañes	n/a M. Aripia	out) form	A. Arailes	n/a
Eff. Date	Rev. No			Details of Cha	ange		1 1/	3, 2024		



WORK INSTRUCTION Effectivity Date: April 26, 2024												
		Process Name/Title:		TAPING AS	SEMBLY PROC	CESS	Validity Date:	n/a				
		Model code/Part number:	930B /	7N0205-7020Ca Cu	stomer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-87	7D		
		Purpose:	PROTOTYPE	☐ PRI	E-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 5		
PARTS:	1. Assy 2. Black						JIG:	n/a				
NO.	I	PROCESS NAME		WORK PROCE	TOOLS/PPE	QUALITY POINTERS						
				Note: Do not exer excessive force duris	1. Fix the co	errugated tube .		Vise Y visualiza actual si Control of the second side of the	ant reminders/I YELLOW TAPE for ation of shifting li hould be BLACK e use calibrated/v ing tape when get ement. ent references:	easy nes, but <u>TAPE.</u> erified		
2	P4	Y-taping 1	tape	pulling 8 winding of tape 25±3mm irection 25±3mm 25±3mm shifting 1/2	2. Start tapin Corrugated to 2 corrugated 3. Winding the other side of a 25mm. Tap 25 5. Winding the tape	g at the middle of combined ubes, then winding the tape going to tubes, width must be Tape width. e tape 1/3 shifting until it reach the corrugated tube, width must be e shifting 9mm below ± 3mm 25 ± 3mm 21/2 shifting going to other side of en cut the tape. After taping, check e.	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9 1 1 2 3 7 8 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1. References 1. No wrong	r to WI-PRO-ASY-	001 for Taping		

				WORK INSTRUC	Effectivity Date:	April 26, 2024					
		Process Name/Title:		TAPING AS	SEMBLY PRO	Validity Date:	n/a				
		Model code/Part number:	930B /	7N0205-7020Ca Cu	ustomer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-87	7D	
		Purpose:	PROTOTYPE	☐ PR	E-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 5	
PARTS:	1. Assy 2. Black	tape					JIG:	n/a			
NO.	F	PROCESS NAME		WORK PROCE	EDURE/ ILLUSTF	RATION	TOOLS/PPE	QUALITY POINTERS			
3	P4	Y-taping 2	tape	Note: D not exer excessive force during winding tape	1. Fix the control of	orrugated tube . Ing at the middle of combined tubes, then winding the tape going to a tubes, width must be Tape width. The tape 1/3 shifting until it reach the corrugated tube, width must be to be shifting 9mm below The shifting 9mm below	MEASURING TAPE	1. Use Y visualiza actual sl 2. Please measurin measure Docume 1. Refer process	ent references: to WI-PRO-ASY-0	easy nes, but TAPE. erified ting the	

				WORK INSTRUCTION	Effectivity Date:	April 26, 2024			
	Process Name/Title:			TAPING ASSEMBLY PR	Validity Date:		n/a		
	5	Model code/Part number:	930B /	7N0205-7020Ca Customer: TRJ		Document No.:		WI-ENG-PDE-8	
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 5
PARTS:	n/a					JIG:	n/a		
NO.	F	PROCESS NAME		WORK PROCEDURE/ ILLUS	TRATION	TOOLS/PPE	(QUALITY POIN	TERS
4	P4	Measurement	(a) 16:13 (b) 15:13 (c) 15	9.35:3 Ps.3 (COTIS) Very tube (8) 24	© 25:3 © 25:3 (S) 0 5:5 (S) 0 7:5 (S		1. No wror	ng dimension	

			WORK INSTRUCTION								Effectivity Date:		April 26, 2024	
			Process Name/Title:	TAPING ASSEMBLY PROCESS Validity Date:		Validity Date:	n/a							
			Model code/Part number:	930B	1	7N0205-7020Ca	Customer:	TRJ	Car Model:	TOYOTA 4RUNNER	Document No.:		WI-ENG-PDE-8	77D
			Purpose:	☐ PF	ROTOTYPE		PRE-LAUNCH	l	MASSP	RO	Revision No.:	1	Page No.:	5 of 5
- 1 [
	PARTS:	n/a									JIG:	n/a		
H														
	QUALITY CHECKPOINTS													

P4

7N0205-7020Ca



1 No Missing Tape (Y-TAPING)

No Wrong Facing (Y-TAPING)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.