WORK INSTRUCTION Effectivity Date: January 21, 2025												
			Process Name/Title:		APING ASSEMBLY PROC	CESS	٧	alidity Date:		n/a		
	- 1		Model code/Part number:	920B / 7R0115-70	21A Customer: TRMX	Car Model: TOYOTA-TACO	MA	ocument No.:		WI-ENG-PDE-6	55A	
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	R	tevision No.:	3	Page No.:	1 of 6	
PARTS:		1. Assy parts; Black twist tube 2420F Ø5 L=189±4mm; AVSSf 0.3 wires B L=534±3mm; Black tape							1. Insertion	1. Insertion jig		
NC).	Р	ROCESS NAME	W	ORK PROCEDURE/ ILLUSTR	RATION		TOOLS/PPE	(QUALITY POINTERS		
						Safety Instruction Be sure to wear prescribed persona protective equipme during operation (gloves, finger cots etc.)	Importa	Important reminders/Note/s: 1. Refer to WI-ENG-PDE-675 for Offline assembly process				
1		P1	Table lay-out		Assy parts	Total and the second se		Housekeeping 1. Maintain and alwa practice 5's. 2. Personal things of the workplace is prohibited. Keep it in your locker. Alert level For any trouble, infoothe Assembly Assists Supervisor or Line Leader for immedia corrective action.	and Stri	2. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance 1. No missing parts/tools 2. No excess parts/tools		
				Insertion jig	AVSSf 0.3 wires B L=534±3mm	Black tape/ Tape holder	40					
	Revision History								Reviewed by	Approved by	Noted by	
01/21/25				ure to QC claim (Not fully inserted).		D.Castillo C.Villanueva A. Arañes	N/A	<u> </u>				
10/09/24			Taping 2 to P2 due to process in al inspection/Quality checkpoint		OTA-TACOMA". Improved Table lay-out	D.Castillo C.Villanueva A. Arañes	N/A	·				
05/19/23			·	asspro. Inclusion of table lay-out. Transfe	er process to Offline assembly process.	D.Castillo J.Loterte C.Villanueva	A. Arar	- Cours	South) Hours	John How		
03/21/23	0	Initial issu	Je.		D.Castillo J.Loterte C.Villanueva	A. Arar	nes D. Castillo	C. Villanueva	A. Arañes	n/a		

Revised Reviewed Approved

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

Eff. Date Rev. No



Details of Change

March 21, 2023

			V	Effectivity Date: January 21, 2025					
		Process Name/Title:		TAPING ASSEMBLY PROC		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0115	-7021A Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-65	55A
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	3	Page No.:	2 of 6
PARTS:	1. Assy	parts				JIG:	1. Insertion jig		
NO.	F	PROCESS NAME	TOOLS/PPE	QUALITY POINTERS					
2	<u>/</u> 3	Connector setting to insertion jig 7189-0995 (W) (Assy parts)	Connector Orientation 2.	Slider Adjustal Guide Release	1. Slide the slide lock using right thumb.	II/a	1. Canno connect 1. Use prov 2. No wrong 3. No wrong	ant reminders/ot insert the inveror. ided jig per model gusage of parts gorientation of conneged connector	ted

			WC	Effectivity Date:	de: January 21, 2025				
		Process Name/Title:		Validity Date:		n/a			
		Model code/Part number:	Car Model: TOYOTA-TACOMA	Document No.:		5A			
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPRO	Revision No.:	3	Page No.:	3 of 6
PARTS:	1. Assy 2. AVS	parts Sf 0.3 wires B L=534±3mm [2	pcs]			JIG:	1. Insertion	jig	
NO.	F	PROCESS NAME	TOOLS/PPE	QUALITY POINTERS					
3		Wire insertion to assy parts	Black SV Tube (Vinyl) Ø7 L=267±3mm	R	1. Hold the SV tube (Vinyl) Ø7 L=267±3mm using left hand and get 2 pcs of Black wire then insert using right hand.	n/a		ng use of parts rmed terminal	
4	P1	Wire insertion to Connector 7189-0995 (W)	1. Get the Black wire then insert to terminal slot 1 using right hand. Conduct Pull-Push-Pull-Push after insertion.	2. Press the button using left hand. The slot for Black wire will be opened. 4. Slide the lock using right thumb and then hold the wires and gently pull out the connector from jig using left hand.		n/a	4. No defo 5. No wror 6. No term Importa 1. Please 2. Make inserted Conduct insertion Do not e 3. Insert conduct method. 4. Insert wire will 5. Conduct removin 6. Pushi by one o	ng insertion one insertion rmed terminal rg wire facing inal backing out ant reminders/N e hold the wire ne sure wires are pro t Pull-Push-Pull-P cion jig will alarm i	ar terminal. operly ush after f will not ush f Yellow 5 seconds. res after rom jig. e done one vires 29 for Pull-

			Effectivity Date:	-							
		Process Name/Title:		TAPING ASSEM	IBLY PROCE	ESS	Validity Date:		n/a		
		Model code/Part number:	920B / 7R0115-70	021A Custome	er: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-655	iΑ	
		Purpose:	☐ PROTOTYPE	☐ PRE-LAU	NCH	■ MASSPRO	Revision No.:	3	Page No.:	4 of 6	
PARTS:	1. Assy 2. Black	parts twist tube 2420F Ø5 L=189±4	4mm	3. Black	tape		JIG:	Insertion njig with switch cover			
NO.	Р	ROCESS NAME	V	VORK PROCEDUR	RE/ ILLUSTRA	TION	TOOLS/PPE	QUALITY POINTERS			
5	P1	Spot taping 1		100±3mm 4 5 6 7 8	2. Get the Black taping on the Bla	1. Hold the wires using left hand and measure from wire up to terminal pointed tip 100±3mm.	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. No flip-ou 2. No peel-o 3. No loose 4. No missin 5. No wrong 6. No wrong 1. Please	e alignment tole to tape if tape tape g dape g dape use of tape int reminders/No use calibrated/vei g tape when gettin	orance 1 mm	
6		Wire insertion to Black twist tube 2420F Ø5 L=189±4mm		R		nck Twist tube 2420F <mark>Ø5</mark> using right hand then insert the ng left hand.			use of parts ned terminal		


			WORK INSTRI	Effectivity Date:	January 21, 2025				
		Process Name/Title:		ASSEMBLY PROC		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0115-7021A	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-65	55A
		Purpose:	☐ PROTOTYPE ☐	PRE-LAUNCH	MASSPRO	Revision No.:	3	Page No.:	5 of 6
PARTS:	1. Assy	parts PROCESS NAME	WORK PRO	JIG: TOOLS/PPE		. Insertion jig			
7	P1	Taping 2 Twisted tube to wire near terminal	1. Measure from Black twist tube 2420 66±3mm up to terminal tip.	R 2. Ho Get E	Start taping R Slack tape using right hand. Start taping, Check the surrement taping condition and alignment.		6. No wrong 7. No insuff Impor 1. Pleas measuri measure	off tape tape ng tape g use of tape g dimension icient tape tant reminders e use calibrated/ve ng tape when getti ment.	erified ing the

			Effectivity Date: January 21, 2025								
	Pro	ocess Name/Title:	TAPIN	Validity Date:	n/a						
	Mo	odel code/Part number:	920B / 7R0115-7021A	C	Customer:	TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-65	5A
	Pu	urpose:	☐ PROTOTYPE	□Р	PRE-LAUNCH		MASSPRO	Revision No.:	3	Page No.:	6 of 6
PARTS:	1. Assy par	rts						JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P1

7R0115-7021A



- 1 No Terminal BackingOut
- 2 No Missing tape(Black tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY