				WORK INSTRUCTION						
1					Effectivity Date:		July 13, 202	23		
		Process Name/Title:	Validity Date:	ity Date: n/a						
	. 1 <b>17</b>	Model code/Part number:	320B / 7I	<b>L0054-7025</b> Customer: <b>TRQSS</b>	Car Model: <b>TO</b>	YOTA-RAV4	Document No.:		WI-ENG-PDE-1	41A
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	7	Page No.:	1 of 4
PARTS:	1. Assy	parts; Black corrugated tube (n	o slit) ø5 L=109±3mm; Black	: VM tube (Sunprene) ø5 L=101±3mm; Green tape			JIG:	1. Terminal c	over jig	
NO.	F	PROCESS NAME		WORK PROCEDURE/ ILLUSTRA	ATION		TOOLS/PPE	(	QUALITY POIN	ITERS
1	P1	Table lay-out		(no slit) Ø5 L=109±3mm  Assy parts	ck VM tube Sunprene) =101±3mm  Green tape Tape Holde		Safety Instruction Be sure to wear prescribed personal protective equipmer during operation (glov finger cots, etc.)  Housekeeping 1. Maintain and alwa practice 5's. 2. Personal things on t workplace is prohibite Keep it in your locker  Alert level For any trouble, infor the Assembly Assistal Supervisor or Line Lear for immediate correct action.	ys 1. No missing the 2. No excess ed. r.		
	lu · ·	IT 1. 1. 1	AODEL HTOVOTA DAVING	Revision History		1 1	Prepared by	Reviewed by	Approved by	Noted by
07/13/23	7 checkp 4) from	oints; Remove and transferred p P2 to P1 due to new process d	process no. 3 and 5 from P1 istribution. Refer to ENGDRF	pdated Table lay-out illustration; Change Quality to P2; Transferred process of Taping 1 (page 3, process R-125 for Document revision request	M. Ariola J. Lote	rte C. Villanueva A. A	Arañes			
02/08/22	6 Quality	check point (Page 4).	• • • •	Black sunprene tube to VM tube (Sunprene). Inclusion of	D.Castillo J. Loter	rte C. Villanueva A. A	Arañes Muelu	$\bigcirc$ 4.1	1/4-4	ALA
	5 chip(7N	e part number from 7L0054-702 I0994-7060);Change in wire col	or from Gray (GR) to Green (		K. Doria J. Loter	A. A	Arañes M. Ariola	J. Loterte	C. Villanueva	A. Arañas
Eff. Date Re	v. No		Details of Cha	nge	Revised Review	ved Approved N	oted Est. Date:	July 12, 2018		

		WORK INSTRUCTION							Effectivity Date:		July 13, 2023		
		Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:		n/a				
		Model code/Part number:	320B /	7L0054-7025	Customer:	TRQSS	Car Model:	TOYOTA-RAV4	Document No.:			WI-ENG-F	DE-141A
		Purpose:	PROTOTY	PE	PRE-LAUNCH		MASSPRO	)	Revision No.:		7	Page No.:	2 of 4
	1	•											
PARTS:	1. Assy 2. Black	parts corrugated tube (no slit) ø5 L=	=109±3mm		3. Black VM	tube (Sunprene	e) ø5 L=101±3	Bmm		JIG	1. Termir	nal cover jig	
NO.	Р	ROCESS NAME		WORK P	ROCEDURE/	ILLUSTRAT	ΓΙΟΝ		TOOLS/PPE		Q	UALITY F	POINTERS
2	P1	Wire insertion to Black corrugated tube (no slit) ø5 L=109±3mm	insert the G-B/W v	cover jig using right hand to vires using left hand.	3. After cover jig		ising right hand using left hand.		TERMINAL COV	ER JIG		rong usage o	
3		Wire insertion to Black VM tube (Sunprene) ø5 L=101±3mm	L			Black VM tube t hand then inse			n/a			rong usage o	

			:	July 13, 2023				
		Process Name/Title:	TAPING ASSEMBLY PROCESS Validity Date:		n/a			
		Model code/Part number:	320B / 7L0054-7025 Customer: TRQSS Car Model: TOYOTA-RAV4 Document No.:		WI-ENG-PDE-141A			
		Purpose:	□ PROTOTYPE   □ PRE-LAUNCH   ■ MASSPRO   Revision No.:		7 Page No.: 3 of 4			
	1							
PARTS:	1. Assy 2. Greei			JIG	n/a			
NO.	Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION TOOLS/F	PPE	QUALITY POINTERS			
4	P1	Taping 1 Black VM tube (Sunprene) to Wire near terminal	1. Hold the sunprene tube using left hand and measure from end of VM tube (Sunprene) up to terminal pointed tip 59±3mm.  2. Hold the VM tube (Sunprene) using left hand. Get the Green tape using right hand and begin taping process using both hands.  3. After taping, check the measurement, terminal alignment and taping condition.	5 6 7 8 9	Important reminders/Note/s:  1. Please use calibrated/verified measuring tape when getting the measurement.  2. Please refer to WI-PRO-ASY-001 for taping procedure.  Wire alignment tolerance  0 - 1 mm			

WORK INSTRUCTION	Effectivity Date:	July 13, 2023	
Process Name/Title: TAPING ASSEMBLY PROCESS	Validity Date:	n/a	
Model code/Part number: 320B / 7L0054-7025 Customer: TRQSS Car Model: TOYOTA-RAV4	Document No.:	WI-ENG-PDE-141A	
Purpose: Prototype Pre-Launch Masspro	Revision No.:	7 Page No.: 4 of 4	
		1	
PARTS: n/a	JIG	n/a	
QUALITY CHECKPOINTS	•		
P1 7L0054-7025			
GOOD  SOOD  NO GOOD  NO GOOD	3	GOOD NO GOOD	
No Unlock/ Half Lock Connector  No Wrong use of ta	oe (GREEN)		
2 No Wrong Insert 4 No Terminal Backing	g Out		