

Mode code-Part number: 010	WORK INSTRUCTION Effectivity Date:										September 12, 2024				
PARTS: 1, All parts: Connector 6188-0477 (VI); TVSS 0,3 wires G 1 = 558-5mm; VSS 0 3 wires BVI L = 558-5mm; Black VM flube (Surprene) 05 J/G: 2, Measuring Jig With switch cover 2, Measuring Jig Vissor Computed Name 96 L = 563-4mm; No alig; Ciph type clamp 8271-11-580(VI); Black type No. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TABLE LAY-OUT Black VM flube (Surprene) 05 J/G: 1, Incertion Jig with switch cover 2, Measuring Jig Vissor No. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TABLE LAY-OUT Safety Instruction Be stare to wear proscribed personal protective equipment during operation (groves, Inger cots, ob), 1, 1, 259-2 mm Connector 1188-0407 (VI) TVSS 0.3 WIRES G L = 558-5mm Connector 1188-0407 (VII) TVSS 0.3 WIRES G L = 558-5mm Connector 1188-0407 (VIII) TVSS 0.3 WIRES G L = 558-5mm Table Lay-out Table Lay-out Revision No.: 1 Page No.: 1 of 8 WORK PROCEDURE/ ILLUSTRATION TOOLS/PE QUALITY POINTERS Safety Instruction Be stare to wear proscribed personal protective equipment during operation (groves, Inger cots, ob), 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,				Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:			n/a			
ARTS: 1. All parts: Connector 6189.0407 (W): TVSSI 0.3 wires G Le 559a2mm; Plack VM tube (Sunprone) 95 Le 125e2mm; Black Corrugated tube 65 Le 363e4mm (No sid); Clip type clamp 8271-1E380(W); Black tape NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TABLE LAY-OUT Black VM tube (Sunprone) 95 J/G: 2. Measuring jig TABLE LAY-OUT Safety Instruction Black corrugated (gloves, finger costs, etc.) 1. P1 Table Lay-out Table Lay-out Tyssr 0.3 wires Revision Natury Revision Nat				Model code/Part number:	010B / 7L0030	0-7024A Customer: TRQSS	Car Model:	TOYO	TA CAMRY	Docu	ment No.:			WI-ENG-PDE-10)31
L=126±3mm; Black Corrugated tube 65 L=363±4mm (No sit); Clip type clamp 82711-1E360(W); Black tape NO. PROCESS NAME TABLE LAY-OUT Black VM tube (Sungeree) (Sunger				Purpose:	PROTOTYPE	PRE-LAUNCH	MASSE	PRO		Revis	sion No.:		1	Page No.:	1 of 8
TABLE LAY-OUT Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)	PARTS:							/M tube (S	unprene) Ø5						
Connector 6198-0407(W) Black VM tube (Supprese) (Suppr	NO	٠.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION								TOOLS/PPE		C	QUALITY POIN	TERS
1 Change pre-launch to mass pro. A.Hernandez C.Villanueva A. Arañes n/a 19/09/24 0 Initial issue A.Hernandez C.Villanueva A. Arañes n/a	1		P1	Table Lay-out	TVSSf 0.3 WIRES B/W L=558±3mm	Blad (s Ø5, L Clip type clamp 82711-1E360(W) TVSSf 0.3 W L=558±31	unprene) =125±3mm RES G	tube s L=363±	Ø5, 3mm	1. 2. P	Be sure to wear prescribed person rotective equipme during operation gloves, finger cotetc.) Housekeeping Maintain and alw. practice 5's. Personal things the workplace is rohibited. Keep it your locker. Alert level or any trouble, infort Assembly Assist Supervisor or Lineader for immedia corrective action.	al ent s, s, s ays ays on 1. 2. in ent tant e	1. Refer to Strip Leng . No missin . No excess	wil-pro-cnc-or ht tolerance.	17 for Wire and
9/09/24 0 Initial issue A. Arañes n/a A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a					TOVI	,					Prepared by	Kevie	ewed by	Approved by	Noted by
Ff. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: September 09, 2024	09/12/24	0									Orlyn Christer A.Hernandez	C. Vill	f) form	A. Araños	n/a
	Eff. Date R	ev. No			Details of Change		Revised	Reviewed	Approved No	oted	Est. Date:	Septemb	er 09, 2024		











			WORK INST	Effectivity Date:	September 12, 2024				
		Process Name/Title:	TAPING	Validity Date:					
		Model code/Part number:	010B / 7L0030-7024A		SS Car Model: TOYOTA CAN	NRY Document No.:		WI-ENG-PDE-10)31
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 8
PARTS:	1. Black VM tube (Sunprene) Ø5 L=125±3mm					JIG:	n/a		
NO.	P	ROCESS NAME	WORK PF	TOOLS/PPE	C	QUALITY POINTERS			
5	P1	Wire Insertion to Black Corrugated tube Ø5 L=363±4mm (no slit)	1. Get the terminal cover jig using right hand then insert G and B/W wires using left hand.	2. Ge slit) u B/W s	It the Corrugated Ø5 L=363±4mm (not sing right hand and insert the GR and wires using left hand			g use of parts med terminal	
6		Wire insertion to Black VM tube (Sunprene) Ø5 L=125±3mm	1. Get the VM tube (Sunprene)Ø5 L and Black/White wire using left han	_=125±3mm using righ d.	R thand then insert the Green	n/a		g use of parts med terminal	

WORK INSTRUCTION Effectivity Date: September 12, 2024												
		Process Name/Title: TAPING ASSEMBLY PROCESS Validity Date:							n/a			
		Model code/Part number:	010B / 7L0030-7024A Customer:	TRQSS C	Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-10	031		
		Purpose:	☐ PROTOTYPE ☐ PRE-LAUNC	Н	MASSPR	RO	Revision No.:	1	Page No.:	5 of 8		
PARTS: 1. Black tape 2. Assy parts JIG: n/a												
NO.	F	PROCESS NAME	WORK PROCEDURI	TOOLS/PPE	(QUALITY POINTERS						
7	P1	Taping 1 VM tube (Sunprene) to wire near terminal	1. Measure the end of the sunprene tube up to the end of the terminal pointed tip 59mm using both hands. 20±3mm 20±3mm 3. After taping, check the measurement condition.	39± 3mm	et the Black d. Hold the stand then stals.	R stape using right sunprene tube using tart taping using both		1. No loose 2. No peel- 3. No flip-c 4. No wron 5. No wron Importa 1. Please of tape when Docume	e tape off tape out tape guse of tape g dimension nt reminders/n use calibrated/verin getting the measu ent reference/s.	ote/s: fied measuring urement.		





		WORK IN	ISTRUCTION		Effectivity Date:		September 12, 2	2024	
	Process Name/Title:	TAPI	NG ASSEMBLY PRO		Validity Date:		n/a		
	Model code/Part number:	010B / 7L0030-7024A	Customer: TRQS	S Car Model: TOYOTA CAMRY	Document No.:	WI-ENG-PDE-103		031	
	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	8 of 8	
PARTS: 1. As	sy parts				JIG:	n/a			
·			QUALITY CH	ECKPOINTS	•				
ТА	PING - P1			7L0030-7	024A				
	Deformed Termi Wrong Insert			nal Backing Out	5 No Miss	ing Tap	G		