WORK INSTRUCTION											Effectivity Date:		February 13, 2024		
			Process Name/Title:		ING ASSEMBLY						lity Date:			n/a	
		5	Model code/Part number:	780B / 7R0104-7023	Customer:	TRMX	Car Model:	TOYOT	A-TUND	RA Docu	ıment No.:			WI-ENG-PDE-5	57C
			Purpose:	PROTOTYPE	PRE-LAUNCH		MASSP	RO		Revis	sion No.:		4	Page No.:	1 of 5
PARTS:		1. Assy բ	parts; Yellow tape							JIG:		n/a			
N	0.	PF	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		QUALITY POINTERS				
1	I	P3	Table Lay-out		Y	ape holder (ellow tap	da d			f pi	afety Instructi Be sure to wear prescribed persor rotective equipm during operatior gloves, finger coretc.) Housekeepin Maintain and ally practice 5's. Personal things the workplace is prohibited. Keep in your locker. Alert level or any trouble, infer e Assembly Assis Supervisor or Lireader for immedicorrective action	g vays 1. 2. Stant the atte		ng parts/tools ss parts/tools	
				Revision History	<u>'</u>		<u> </u>		1		Prepared by	Revie	wed by	Approved by	Noted by
02/13/24	4	Inclusion of Car model "TOYOTA-TUNDRA"					D.Castillo	C. Villanueva	A. Arañes	n/a	_				
01/19/23				near terminal hotmelted wires then transfer to ssing tape and out of tolerance. Inclusion of Qu		and 8 from	M. Ariola	J. Loterte	C. Villanueva	A. Arañes	Jestino	I /mil.	12 illow	Alax	
11/10/22		Improve Q	Quality pointers; Reminders/Not	e/s and references on page no. 1,2,3 and 5 du	e to document improveme	nt.	M. Ariola	J. Loterte	C. Villanueva	A. Arañes	rañac /		C. Villanueva A. Arajnes n		n/a
Eff. Date	Rev. No	Details of Change					Revised	Reviewed	Approved	Noted	Est. Date:	July 19, 20	022		



	_		WORK INS	Effectivity Date:	February 13, 2024						
		Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:	n/a			
		Model code/Part number:	780B / 7R0104-7023A	Customer: TRMX	Car Model:	TOYOTA-TUNDRA	Document No.:		WI-ENG-PDE-55	57C	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	4	Page No.:	2 of 5	
PARTS:	1. Assy 2. Yello	sy parts Ilow tape [1pc]				JIG:	N/A				
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR/	ATION		TOOLS/PPE	(QUALITY POIN	ΓERS	
2	P3	Taping 4 Black SV tube (Vinyl) to wire near connector	25±3mm L Start of taping R tape width 25±3mm 0-5mm	2. Hold the SV tube (Vinyl) tape using right hand and st hands.	using left har tart taping pro	inyl) using left hand. Inyl tube up to Ing both hands. Ind. Get the Black Incess using both		Importa 1. Please measuring measuren 2. Set asid 3. Use YI	out tape e tape ng use of tape ng use of tape ng dimension out reminders/ne use calibrated/ven g tape when getting ment. de the assy part aft ELLOW TAPE only ment references e refer to WI-PRO-	ified g the ter assembly. y.	

NBC (Philippines)
MASTER COPY

			WORK INS	Effectivity Date:	February 13, 2024					
		Process Name/Title:	Validity Date:	n/a						
		Model code/Part number: 780B / 7R0104-7023A Customer: TRMX Car Model: TOYOTA-TUN				TOYOTA-TUNDRA	Document No.:	Document No.: WI-ENG-PDE-557C		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	4	Page No.:	3 of 5
PARTS:	1. Assy 2. Yello	parts ow tape [1pc]					JIG:	N/A		
NO.	F	PROCESS NAME	WORK F	TOOLS/PPE	QUALITY POINTERS					
3	P3	Y-Taping		pre-tape before 3. Make 1 wine	at the middle obes & vinyl tubre shifting.	of combined le, make 1 winding yl tube & corrugated with tape (19mm).		Importa 1. Please measurin measurer 2. Use YE 3. Must b tube and	out tape e tape ng use of tape ng dimension ant reminders/m use calibrated/ver g tape when gettin ment. ELLOW TAPE only e no gap between Vinyl. ent references: refer to WI-PRO-A	rified g the



			Effectivity Date:	February 13, 2024								
		Process Name/Title:	TAPIN	NG ASSEMBLY PROC	CESS		Validity Date:		n/a			
		Model code/Part number:	780B / 7R0104-7023A	Customer: TRMX	Car Model:	TOYOTA-TUNDRA	Document No.:		WI-ENG-PDE-5	57C		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	4	Page No.:	4 of 5		
		parts w tape					JIG:	N/A				
NO.	F	PROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS							
3	P3	Y-Taping (Continuation)	1/2 below	5. Wind the te tape 6. Wind the to other side of tape. 7. After	tape 1/2 shiftir corrugated tub	tape shifting 1/2 below and 1/2 shifting.	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 WALLE LANGE MADE SO AND	1. Pleas measurismeasure 2. Use Y 3. Must tube and Docum 1. Pleas taping p 1. No peel 2. No flip o 3. No loos 4. No wroi	be no gap between a Vinyl. nent references be refer to WI-PRO- rocedure. off tape but tape	rified ing the ly. It the Corrugated		



			WORK INS	Effectivity Date:	February 13, 2024				
		Process Name/Title:	TAPIN	Validity Date: n/		n/a	a		
		Model code/Part number:	780B / 7R0104-7023A	Customer: TRMX	Car Model: TOYOTA-TUNDRA	Document No.:		WI-ENG-PDE-5	57C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	4	Page No.:	5 of 5
PARTS:	N/A					JIG:	N/A		
QUALITY CHECKPOINTS									



1 No Missing tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY