			WORK INSTRUCTION					Effectivity Date:		September 22, 2022	
			Process Name/Title:		ASSEMBLY PR	OCESS		Validity Date:		n/a	
			Model Code/Part Number:	220D / 7L0135-7020	Customer:	TRQS	SS	Document No.:		WI-ENG-PDE-	157
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 5
PARTS:		1. All parts: Connector 6098-3802		/); AVSSf 0.3 B-V L=796±3mm; Black Vinyl tube ø5 L=181±3mm		JIG: 1. Insert		nsertion jig with switch cover			
N	NO.		PROCESS NAME	WORK PRO	WORK PROCEDURE/ ILLUSTRATION		TOOLS/PPE	G	QUALITY POINTERS		
1		n/a	Table Lay-out	Connector 6098-3802 (W) /Connector Tray  Insertion Jig A with flip cover  Locking Jig	AVSSF 0.3 B-V L=	Black Vinyl tube ø5 L=181±3mm		Safety Instruction  Be sure to wear required personal protective equipmen during operation (gloves, finger cots, etc.)  Housekeeping  1. Maintain and alway practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistan Supervisor or Line Leader for immediate corrective action.	Document  1. Refer to 1 Length Tole  1. No missir 2. No exces	reference/s: 1 NI-PRO-CNC-017 for rance  ag parts/tools s parts/tools	Wire and Strip
				Revision History				Prepared by	Reviewed by	Reviewed by	Approved by
09/22/22	'	improve	ment. Work procedure/illustration	tes and references in process no.1,2,3,4 and 5 d on in process no.4 - connector lock		M. Catapang J. Loterte	C. Villanueva A. Ar	rañes Manual Tanan	(An)	Nouth ) Hour	
03/28/22		Initial iss	sue.	Data its of Ohana		K. Doria J. Loterte	C. Villanueva A. Ar	añes M. Catapang	J. Loterte	C. Villanueva	A. Arabes
Eff. Date	Rev. No			Details of Change		Revised Reviewed	Approved No	eted Est. Date: M	March 28, 2022		

		WORK INSTRUCTION						September 22, 2022		
		Process Name/Title:	OFFLINE A	SSEMBLY PR	OCESS	Validity Date:			n/	a
		Model Code/Part Number:	220D / 7L0135-7020	Customer:	TRQSS	Document No.:			WI-ENG-I	PDE-457
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:		1	Page No.:	2 of 5
								1		
PARTS:	1. Connector 6098-3802 (W)					JIG		Insertion jig with switch cover		
NO.	P	ROCESS NAME	WORK PROC	RK PROCEDURE/ ILLUSTRATION			PPE	QUALITY POINTERS		OINTERS
2	n/a	Connector setting to insertion jig 6098-3802 (W)	v-wire		Connector Orientation  Release  Onnector 6098-3802 into jig using d release the lock.  Hole  January 1 and 1 and 2 and 3	n/a		I-mark not align  Good  Good  1. Use p  2. No wi  3. No wi	is GO  CONNECTOR II  Torovided jig prong usage or gong usa	AG  LLUSTRATION  NG  6098-5668 (W)  per model  of parts  ation of connector

			WORK INSTRU	CTION		Effectivity Date:		September 22, 2022		
		Process Name/Title:	OFFLINE A	Validity Date:			n/a			
		Model Code/Part Number:	220D / 7L0135-7020	Customer:	TRQSS	Document No.:		W	/I-ENG-PDE-	457
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:		1 Pag	ge No.:	3 of 5
		<u> </u>						1	l .	
PARTS:	1. AVS	Sf 0.3 B-V L=796±3mm					JIG	1. Insertion	jig with switcl	n cover
NO.	Р	ROCESS NAME	WORK PROC	CEDURE/ ILLU	JSTRATION	TOOLS/F	PPE	QUALITY POINTERS		
3	n/a	Wire insertion to connector 6098-3802 (W)	1. Get the Violet wire then insert to terminal slot 1 using right hand.  Black 2  Black 2  3. Get the Black wire then insert to terminal slot 2 using right hand.	4. After it thumb ai	Press R  After insertion of Violet wire press the cton using right hand. The slot for ck wire will be opened.  Represe R  Press R  After insertion of Violet wire press the cton using right hand. The slot for ck wire will be opened.	n/a	<u>/-</u>	1. Please he terminal. 2. Make suinserted. Conduct Plafter insert Do not exert Document I. Refer to G. Push procedu 2. Refer to W.	g insertion ne insertion ned terminal g wire facing reminders/No old the wire i re wires are ull-Push-Pu tion. rt extra force references:	properly  Ill-Push  .  9 for Pull- 7 for Wire

		WORK INSTRUC	TION		Effectivity Date:	September 22, 2022
	Process Name/Title:	OFFLINE AS	SEMBLY PROCESS		Validity Date:	n/a
	Model Code/Part Number:	220D / 7L0135-7020	Customer:	TRQSS	Document No.:	WI-ENG-PDE-457
	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 4 of 5
					1	
PARTS: n/a		۸			JIG	1. Locking jig
NO.	PROCESS NAME	1 WORK PROCE	DURE/ ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS
4 n.	/a Connector Lock	1. Load the connector into the jig holding both side of the connector, tip first.  Right thumb-Lower Left thumb-middle  3. Press the lower parts of connector using rig hand while left hand holding the middle.  Right thumb-middle Left thumb-middle  5. Lift then press the connector in the middle using left and right hand.	2. Press the lower part of insert into the locking ji  Right thumb	of connector to fully ig.  b-uppermiddle  connector using right ling the middle.	LOCKING JIG	Before pressing  After pressing  NG  NG  Full Lock  Important reminders/Note/s:  1. MANUAL LOCKING MAY CAUSE DAMAGED CONNECTOR  1. Use the provided jig tool to lock the connector.  2. No unlock/half-locked connector

			WORK INST	RUCTION		Effectivity Date:	September 22, 2022		
		Process Name/Title:	OFFLINE	E ASSEMBLY PRO	Validity Date:	n/a			
		Model Code/Part Number:	220D / 7L0135-702	Customer:	TRQSS	Document No.:	WI-ENG-PDE-457		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 5 of 5		
PARTS:	1. Black 2. Assy	Vinyl tube ø5 L=181±3mm parts				JIG	n/a		
NO. F		ROCESS NAME	WORK PF	ROCEDURE/ ILLUSTE	RATION	TOOLS/PPE	QUALITY POINTERS		
5	n/a	Wire insertion to Black Vinyl tube ø5 L=181±3mm	Get vinyl tube ø5 L=181±3mm using righ insert Violet and Black wire using left had	t hand then nd.		n/a	No wrong use of parts     No deformed terminal		