

	7L0051 1RQ55									
No.		Work Procedure/ Illustration						Records/Remarks/ Quality Pointers		
	<u></u>	Put Vinyl Sheet (1250 x 1250) side carton box.				Qty/box Mat'l name	120 Dim.	30pcs*4bdls Qty.		
1			3					DC carton	1131*781	1
							Vinyl sheet	1250*1250	1	
2	Put firs	st bundle of products. (30pcs.)	Plastic vinyl bag of Contact SW assy					Plastic Vinyl bag 420*280 4 Note: 3 Step number 7 is applicable only in QC FG Inspection.		
3	Put secor di	nd bundle with opposite rection (30pcs.)								
4	Put third	I bundle with opposite rection (30pcs.)								
(5)	Put four di	Put fourth bundle with opposite direction (30pcs.)								
<u>\$\sqrt{3}\$</u> 6	Fold the vinyl sheet.									
7	Identifica plas Identifica	he flaps and put NBP tion tag at the top of the tic and Warehouse tion tag at the right side te front of the box	Note: If need to attach 4M tag Put 4M tag at the left side					-		
07/05/2024	3	Change Vinyl Sheet Size from 1520		re of no. 1; Modify no. 6	J. De La Cruz	D.Dadulla	R.Pascua	Prepare	Check	Approve
08/24/2022	2	and Addition of no. 7; Add note. Remove "Note: For CSW process disregard step 4 and			M. Garcia	R. Alcantara	A.Arañes			1. /
06/29/2021 10/01/2018	1 0	use Oricon box instead of DC box" Update Step # 6 and put additional note Initial Issue : Removal of Sting agl and Bubble sheet			C.Dimailig C.Dimailig	M.Lumbres M.Lumbres	E Mendoza E Mendoza	J. De la Cruz	D. Dadulla	M
Eff./Rev. Date	Rev. No.		Details of change		Revise	Check	Approve	Est. date:		1/2018

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

WI-QAD-QAC-048

July 5, 2024

Page 1 of 1

Page No.: