Process Name/Title: Model code/Part number: 100B / 7M0583-7020A Customer: TRJ Car Model: LEXUS-UX Document No.:	n/a WI-ENG-PDE-222 6 Page No.: 1 of 6
Purpose: PROTOTYPE PRE-LAUNCH MASSPRO Revision No.:	-
	6 Page No.: 1 of 6
PARTS: 1. Assy Parts; Black SV tube (Vinyl) Ø5 L=35±3mm; Blue tape JIG:	
	1. Measuring jig
NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE	QUALITY POINTERS
TABLE LAY-OUT Safety Instruction Be sure to wear prescribed person protective equipment during operation (gloves, finger content) Black SV tube (Vinyl) Ø5 L=35±3mm	pal part part part part part part part part
1 P1 Table Lay-out Assy Parts Table Lay-out Table Lay-out Assy Parts Assy Parts Housekeepin 1. Maintain and alw practice 5's. 2. Personal things the workplace is prohibited. Keep if your locker.	on 1. No wrong use of parts 2. No deformed terminal
Measuring jig Tape holder / Blue tape Alert level For any trouble, infi the Assembly Assis Supervisor or Lin Leader for immedia corrective action	tant e ate
Revision History Prepared by	Reviewed by Approved by Noted by
04/25/24 6 Inclusion of Car model "LEXUS-UX"). Transfer Wire insertion to corrugated tube process to Offline assembly process (WI-ENG-PDE-221). Update Measurement and Visual inspection.	
05/17/23 5 Inclusion of table lay-out and quality check points; improvement of important reminders/note/s; improvement of by two's inspection; standardize term for SV tube (Vinyl)	Manto illow
07/08/21 4 Revised due to removal of marking. M. Catapang C. Villanueva A. Shimamura A. Arañes D. Castillo	C. Villanueva A. Arañes n/a
Eff. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date:	October 19, 2018


			WORK INS	TRUCTION				Effectivity Date:		April 25, 2024		
		Process Name/Title:						Validity Date:	n/a			
		Model code/Part number:	100B / 7M0583-7020A	Customer: 1	TRJ C	Car Model:	LEXUS-UX	Document No.:	WI-ENG-PDE-222			
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO		Revision No.:	6	Page No.:	2 of 6	
PARTS:	1. Assy parts 2. Black SV tube (Vinyl) Ø5 L=35±3mm 3. Blue tape [1pc]						JIG:	n/a				
NO.	Р	ROCESS NAME	WORK F	TOOLS/PPE	QUALITY POINTERS							
2		Wire insertion to SV tube (Vinyl) Ø5 L=35±3mm	(L)		R	L=35±3mm	V tube (Vinyl) Ø5 using right hand he B-B wires nd.			g use of parts med terminal		
3	P1	Full taping (From COT to SV tube (vinyl), SV tube (vinyl) to wires near terminal)	Start of taping R 20 ± 3mm 1/3 shift	bo pre	oth hands the re-taping.	en get the Blu	(Vinyl) using e tape and start g going to left COT.	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. Use B. 2. Must b. vinyl tub 2. Please measurin measure 1. Refer i procedur 1. No flip-o 2. No peel- 3. No loose 4. No missi 5. No wron 6. No wron	e use calibrated/ver ng tape when gettin ment. ent reference/s: to WI-PRO-ASY-00 re. but tape -off tape e tape ing tape g dimension ng use of tape re alignment tol	COT and rified gg the	



			WORK INS	Effectivity Date:	April 25, 2024						
		Process Name/Title:		IG ASSEMBLY PRO	CESS		Validity Date:		n/a		
		Model code/Part number:	100B / 7M0583-7020A	Customer: TRJ	Car Model:	LEXUS-UX	Document No.:	WI-ENG-PDE-222			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	6	Page No.:	3 of 6	
PARTS:	1. Assy parts 2. Blue tape [1pc]							n/a			
NO.	F	PROCESS NAME	TOOLS/PPE	(QUALITY POIN	ΓERS					
3	P1	Full taping (From COT to SV tube (vinyl), SV tube (vinyl) to wires near terminal) (Continuation)	3. Make 2 winds before shifting then must tube (vinyl). 1/2 shifting	4. Meas to termi continu	sure from end of inal pointed tip 5 ! e the taping proc	SV tube (vinyl) up 5±3mm then zess. yl) using left hand d. Continue 1/2 e wire. Make 1	TAPE	1. Üse E 2. Must i vinyl tut 2. Pleas measure measure 1. Refer i procedur 1. No flip-c 2. No peel 3. No loosi 4. No miss 5. No wron 6. No wron	e use calibrated/veng tape when gettiement. Int reference/s: to WI-PRO-ASY-Ore. Dut tape -off tape e tape ing tape ng dimension ng use of tape	n COT and erified ng the	

	_		WORK INST	TRUCTION			Effectivity Date:		April 25, 202	4
	\triangle	Process Name/Title:		G ASSEMBLY PROC	ESS		Validity Date:		n/a	
		Model code/Part number:	100B / 7M0583-7020A Customer: TRJ Car Model: LEXUS-UX				Document No.:	WI-ENG-PDE-222		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO)	Revision No.:	6	Page No.:	4 of 6
PARTS:	1. Assy 2. Blue	parts tape [1pc]					JIG:	n/a		
NO.	F	PROCESS NAME	WORK P	ROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POIN	TERS
3	P1	Full taping (From COT to SV tube (vinyl) , SV tube (vinyl) to wires near terminal) (Continuation)	6. Wind the tape 1/2 shifting going to leshifting. 1/2 shifting 7. Continue 1/2 shifting going to right stape.	eft side until it reach the CO	T then make 2 v	R s before cutting of g, check the re alignment and	MEASURING TAPE	Import 1. Use E 2. Must ivinyl tut 2. Pleas measurismeasure 1. Refer iprocedur 1. No flip-c 2. No peel 3. No loos 4. No miss 5. No wron 6. No wron	ant reminders/ BLUE TAPE only. be no gap between be use calibrated/ve ng tape when getti ement. Int reference/s: to WI-PRO-ASY-0 te. Dut tape e-off tape eing tape ing tape	(Note/s: in COT and erified ing the






NB		WORK INSTRUCTION							Effectivity Date:	April 25, 2024		
		Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:	n/a			
		Model code/Part number:	100B / 7M0583-7020A		Customer:	TRJ	Car Model:	LEXUS-EX	Document No.:		WI-ENG-PDE-	222
		Purpose:	PROTOTYPE		PRE-LAUNCH	I	MASSPRO		Revision No.:	6	Page No.:	6 of 6
									1	1		
PARTS:	1. Assy	parts	JIG:	n/a								
6 VISUAL INSPECTION												

TAPING-P1

7M0583-7020A



1

No Missing Tape (Blue tape)

2

No Wrong use of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.