

Process Name/ Title:

PACKING INSTRUCTION

WORK INSTRUCTION

Document No:

Effective Date:

3

WI-QAD-QAC-051

July 5, 2024

Product Code/Name: **7L0033**

Customer Code: TRQSS

Rev. No.:

Page No.:

Page 1 of 1

	7 L0033 TNQ33										
No.		Work Procedure/ Illustration						Records/Remarks/ Quality Pointers			
		Put Viny	l Sheet						Qty/ box	64 pcs.	32 pcs. * 2 bdls.
1	(1250 x 1250) inside carton box.								Material name	Dimension	Quantity
				-				DC Carton		1	
								$\sqrt{3}$	Vinyl sheet Plastic	1250 * 1250 420 * 280	1
									vinyl bag	420 * 280	2
2	Put firs	st bundle (32 p	e of products. cs.)					(011 433)	Note: 3 Step numbe FG Inspection	r 5 is applicabl on .	e only in QC
3			le on upper with direction.				Switches mus of the bundle				
<u>^3</u> <u>4</u>	Fold the vinyl sheet.										
(5)	Close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box .			Note: If need to attach 4M tag Put 4M tag at the left side							
07/05/2024	3	Change Vinyl Sheet Size from 1520.			ure of no. 1; Modify	J. De La Cruz	D.Dadulla	R.Pascua	Prepared	Checked	Approved
12/21/2021	2	no. 4 and A		ddition of no. 5; Modify note. from 28 to 32 and from 56 to 64 po	cs. per box.	D. Dadulla	R. Alcantara	A. Arañes	,	,	1. /
10/01/2018	1 0	13011 0 1 0 1				C.Dimailig C.Dimailig	M.Lumbres M.Lumbres	E Mendoza E Mendoza		May	M
Eff./Rev. Date				gel Details of change		Revise	Check	Approve	J. De Kal Cruz Est. date:	D.Dadutta 10/1/	RI.Pascua 2018

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY