

			WORK INSTRUCTION					Effectivity Date:		May 29, 2024		
	B		Process Name/Title:	Validity Date:		n/a	-					
			Model code/Part number:	TAPING ASSEMBLY PROCESS Validity Date: 990B / 7N0142-7020A Customer: TRJ Car Model: TOYOTA-PRIUS Document No.:				Document No.:	WI-ENG-PDE-453C			
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPE	२०	Revision No.:	0	Page No.:	1 of 5	
PARTS: 1. Assy parts; Black tape								JIG:	n/a			
NO.		PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POINTERS		
1		P3	Table Lay-out	The second secon	Assy parts Black tape/ ape holder	5 6 7 8 9 (1) (2) 1	C PRANTING THE STATE OF THE STA	Safety Instructio Be sure to wear prescribed personal protective equipmer during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things or the workplace is prohibited. Keep it ir your locker. Alert level For any trouble, infor the Assembly Assista Supervisor or Line Leader for immediat corrective action.	/s . 1. No miss 2. No exce	ing parts/ tools.		
				Revision History				Prepared by	Reviewed by	Approved by	Noted by	
05/29/24		Initial iss	ue. e process from P2 Y-taping trans	efer to P3.			C.	n/a A.Hernandez	Sout Tifform			
Eff. Date		Spin type	5 p. 55000 from 1 Z 1-taping trails	Details of Change		1		_	C. Villanueva	✓ A.ħræñés	n/a	
2010	INGV. INU	l .		Details of Change		I/GAI260	Iveriewed Apployed I	Noted JESt. Date. IN	10y 23, 2024			



			Effectivity Date: May 29, 202			.4				
		Process Name/Title:	Validity Date:	n/a WI-ENG-PDE-453C						
		Model code/Part number: 990B / 7N0142-7020A Customer: TRJ Car Model: TOYOTA-PRI					Document No.:			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO	Revision No.:	0	Page No.:	3 of 5
PARTS:	Assy parts Black tape							n/a		
NO.	PROCESS NAME		WORK	TOOLS/PPE	QUALITY POINTERS					
2	P3	Y-Taping (Continuation)	taping direction 1/3 shifting	1/3 shifting going to the rig	taping d 1/3 shifting hifting vire. Measure	mm 0-5mm	Measuring tape	1. Pleas measuri measuri 2. Use Y visualiza actual s. 1. No flip-c. 2. No peed. 3. No loose 4. No miss 5. No wron	e use clibrated ving tape when geement. "ELLOW TAPE foation of tape shifthould be BLACK" Dut tape -off tape e tape	erified etting the er easy eting, but



NIDO		WORK INS	Effectivity Date: May 29, 2024						
	Process Name/Title: Model code/Part number:	TAPIN 990B / 7N0142-7020A	Validity Date:	n/a WI-ENG-PDE-453C					
		PROTOTYPE	Customer: TRJ	Car Model: TOYOTA-PRIUS MASSPRO	Document No.: Revision No.:	0 Page No.:	5 of 5		
	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0 Page No.:	5 01 5		
PARTS: n/a					JIG: n/	/a			
	VISUAL INSPECTION/QUALITY CHECKPOINTS								
Р3	P3 7N0142-7020A								
GOOD		2		3	5	GO			
1 No Unlock / Halflock Connector 4 No Missing / Wrong used of tape									
2 (3	No Wrong In	sert	5	No Defomed Tern	ninal				